

GROUP 00

GENERAL

CONTENTS

HOW TO USE THIS MANUAL	00-3	SCAN TOOL (MULTI USE TESTER { M.U.T.-III } SUB ASSEMBLY)	00-23
TROUBLESHOOTING GUIDELINES	00-6	HOW TO PERFORM VEHICLE IDENTIFICATION NUMBER (VIN) WRITING	00-24
HOW TO USE TROUBLESHOOTING/INSPECTION SERVICE POINTS	00-6	CODING LIST	00-28
TROUBLESHOOTING CONTENTS	00-6	INITIALIZATION PROCEDURE FOR LEARNING VALUE IN MFI ENGINE	00-38
HOW TO USE THE INSPECTION PROCEDURES	00-8	ENGINE IDLING LEARNING PROCEDURE	00-38
CONNECTOR MEASUREMENT SERVICE POINTS	00-10	TIMING CHAIN MAINTENANCE <2.0 L ENGINE>	00-39
CONNECTOR INSPECTION SERVICE POINTS	00-12	SERVICING ELECTRICAL SYSTEM	00-43
HOW TO COPE WITH INTERMITTENT MALFUNCTIONS	00-13	HOW TO SHIFT LOCK FORCED RELEASE	00-44
HOW TO TREAT PAST TROUBLE	00-15	VEHICLE WASHING	00-45
INSPECTION SERVICE POINTS FOR A BLOWN FUSE	00-15	APPLICATION OF ANTI-CORROSION AGENTS AND UNDERCOATS	00-45
VEHICLE IDENTIFICATION	00-16	BOLTS AND NUTS WITH STABILIZER FOR COEFFICIENT OF FRICTION	00-45
VEHICLE IDENTIFICATION NUMBER PLATE	00-16	FORM-IN-PLACE GASKET (FIPG)	00-46
CHASSIS NUMBER	00-18	TOWING AND HOISTING	00-47
VEHICLE INFORMATION CODE PLATE	00-19	TIGHTENING TORQUE	00-51
TIRE AND LOADING INFORMATION PLACARD	00-19	LUBRICATION AND MAINTENANCE	00-52
ENGINE MODEL STAMPING	00-19	RECOMMENDED LUBRICANTS AND LUBRICANT CAPACITIES TABLE	00-54
GENERAL DATA AND SPECIFICATIONS	00-20	SCHEDULED MAINTENANCE TABLE	00-57
PRECAUTIONS BEFORE SERVICE	00-22	<2.0L ENGINE>	00-57
CAUTIONS FOR WORKING IN ENGINE COMPARTMENT <2.0 L ENGINE>	00-22	<2.4L ENGINE>	00-60
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	00-22		

Continued on next page

MAINTENANCE SERVICE

<2.0L ENGINE>	00-63
1. FUEL SYSTEM (TANK, PIPE LINE AND CONNECTION, AND FUEL TANK FILLER TUBE CAP) (CHECK FOR LEAKS)	00-63
2. FUEL HOSES (CHECK CONDITION) ..	00-63
3. AIR CLEANER ELEMENT (REPLACE) .	00-63
4. EVAPORATIVE EMISSION CONTROL SYSTEM (EXCEPT EVAPORATIVE EMISSION CANISTER) (CHECK FOR LEAKS AND CLOGGING) ..	00-63
5. SPARK PLUGS (REPLACE)	00-64
6. INTAKE AND EXHAUST VALVE CLEARANCE (INSPECT AND ADJUST)	00-64
7. DRIVE BELT (FOR THE GENERATOR AND POWER STEERING OIL PUMP) (REPLACE)	00-66
8. EXHAUST SYSTEM (CONNECTIONS PORTION OF MUFFLER, MUFFLER PIPES AND CONVERTER HEAT SHIELDS) (CHECK AND SERVICE)	00-67
9. ENGINE OIL (CHANGE)	00-67
10. ENGINE OIL FILTER (REPLACE)	00-68
11. TWIN CLUTCH-SPORTRONIC SHIFT TRANSMISSION (TC-SST) [CHECK THE FLUID LEAKAGE (IF NECESSARY, CHECK THE FLUID LEVEL) /CHANGE]	00-68
12. TWIN CLUTCH SPORT-SHIFT TRANSMISSION OIL FILTER (CHANGE) .	00-71
13. TRANSFER OIL (WITH ACTIVE CENTER DIFFERENTIAL) (CHECK OIL LEVEL/ CHANGE)	00-71
14. RESERVE TANK FLUID (FOR ACTIVE CENTER DIFFERENTIAL) (CHECK FLUID LEVEL)	00-72
15. ENGINE COOLANT (CHANGE)	00-73
16. COOLANT HOSES (RADIATOR HOSE, HEATER HOSE) (INSPECT)	00-75
17. DISK BRAKE PADS AND ROTORS (INSPECT FOR WEAR)	00-75
18. BRAKE HOSES (CHECK FOR DETERIORATION OR LEAKS)	00-82
19. BALL JOINT AND STEERING LINKAGE SEALS (INSPECT FOR GREASE LEAKS AND DAMAGE)	00-82
20. DRIVE SHAFT BOOTS (INSPECT FOR GREASE LEAKS AND DAMAGE)	00-82
21. SUSPENSION SYSTEM (INSPECT FOR LOOSENESS AND DAMAGE)	00-82
22. REAR AXLE OIL (WITH LSD) (CHANGE)	00-83

23. TIRES (ROTATE)	00-83
24. AIR PURIFIER FILTER (REPLACE) ...	00-83

MAINTENANCE SERVICE

<2.4L ENGINE>	00-63
1. FUEL SYSTEM (TANK, PIPE LINE AND CONNECTION, AND FUEL TANK FILLER TUBE CAP) (CHECK FOR LEAKS)	00-84
2. FUEL HOSES (CHECK CONDITION) ...	00-84
3. AIR CLEANER ELEMENT (REPLACE) ..	00-84
4. EVAPORATIVE EMISSION CONTROL SYSTEM (EXCEPT EVAPORATIVE EMISSION CANISTER) (CHECK FOR LEAKS AND CLOGGING)	00-84
5. SPARK PLUGS (REPLACE)	00-85
6. INTAKE AND EXHAUST VALVE CLEARANCE (INSPECT AND ADJUST) ..	00-85
7. DRIVE BELT (FOR THE GENERATOR AND POWER STEERING OIL PUMP) (CHECK CONDITION)	00-87
8. EXHAUST SYSTEM (CONNECTIONS PORTION OF MUFFLER, MUFFLER PIPES AND CONVERTER HEAT SHIELDS) (CHECK AND SERVICE)	00-88
9. ENGINE OIL (CHANGE)	00-88
10. ENGINE OIL FILTER (REPLACE)	00-89
11. TRANSMISSION OIL <M/T> (CHECK OIL LEVEL AND CONDITION)	00-90
12. TRANSMISSION FLUID <CVT> (CHANGE FLUID)	00-91
13. ENGINE COOLANT (CHANGE)	00-93
14. COOLANT HOSES (RADIATOR HOSE, HEATER HOSE) (INSPECT)	00-94
15. DISK BRAKE PADS AND ROTORS (INSPECT FOR WEAR)	00-95
16. BRAKE HOSES (CHECK FOR DETERIORATION OR LEAKS)	00-101
17. BALL JOINT AND STEERING LINKAGE SEALS (INSPECT FOR GREASE LEAKS AND DAMAGE)	00-101
18. DRIVE SHAFT BOOTS (INSPECT FOR GREASE LEAKS AND DAMAGE)	00-101
19. SUSPENSION SYSTEM (INSPECT FOR LOOSENESS AND DAMAGE)	00-102
20. TIRES (ROTATE)	00-102
21. AIR PURIFIER FILTER (REPLACE) ...	00-102

MAIN SEALANT AND ADHESIVE TABLE**00-103**

HOW TO USE THIS MANUAL

M1001000102826

MAINTENANCE, REPAIR AND SERVICING EXPLANATIONS

This manual provides explanations, etc. concerning procedures for the inspection, maintenance, repair and servicing of the subject model. Unless otherwise specified, each service procedure covers all models. Procedures covering specific models are identified by the model codes, or similar designation (engine type, transaxle type, etc.). A description of these designations is covered in this manual under "VEHICLE IDENTIFICATION."

ON-VEHICLE SERVICE

The "ON-VEHICLE SERVICE" section has procedures for performing inspections and adjustments of particularly important components. These procedures are done with regard to maintenance and servicing, but other inspections (looseness, play, cracking, damage, etc.) must also be performed.

SERVICE PROCEDURES

The service steps are arranged in numerical order. Attention to be paid in performing vehicle service are described in detail in SERVICE POINTS.

DEFINITION OF TERMS

STANDARD VALUE

Indicates the value used as the standard for judging whether or not a part or adjustment is correct.

LIMIT

Shows the maximum or minimum value for judging whether or not a part or adjustment is acceptable.

REFERENCE VALUE

Indicates the adjustment value prior to starting the work (presented in order to facilitate assembly and adjustment procedures, and so they can be completed in a shorter time).

DANGER, WARNING, AND CAUTION

DANGER, WARNING, and CAUTION call special attention to a necessary action or to an action that must be avoided. The differences among DANGER, WARNING, and CAUTION are as follows:

- If a DANGER is not followed, the result is severe bodily harm or even death.
- If a WARNING is not followed, the result could be bodily injury.
- If a CAUTION is not followed, the result could be damage to the vehicle, vehicle components or service equipment.

TIGHTENING TORQUE INDICATION

The tightening torque indicates a median and its tolerance by a unit of N·m (in-lb) or N·m (ft-lb). For fasteners with no assigned torque value, refer to [P.00-51](#).

SPECIAL TOOL NOTE

Only MMC special tool part numbers are called out in the repair sections of this manual. Please refer to the special tool cross-reference chart located at the beginning of each group, for the special tool number that is available in your market.

ABBREVIATIONS

The following abbreviations are used in this manual for classification of model types:

2.0L Engine:1,998cm³ (121.9 cu in) <4B11> engine, or a model equipped with such an engine.

2.4L Engine:2,360 cm³ (144.0 cu in) <4B12> engine, or a model equipped with such an engine.

M/T:Indicates manual transaxle, or models equipped with manual transaxle.

CVT: Indicates the continuously variable transaxle.

TC-SST:Indicates the twin clutch-sportronic shift transmission.

MFI: Multiport fuel injection, or engines equipped with multiport fuel injection.

AWD: Indicates the all wheel drive vehicles.


FWD: Indicates the front wheel drive vehicles.

ECM: Indicates the engine control module

TCM: Indicates the transaxle control module

A/C: Indicates the air conditioning.

EXPLANATION OF MANUAL CONTENTS



Maintenance and servicing procedures

The numbers provided within the diagram indicate the sequence for maintenance and servicing procedures.

- Removal steps :
The part designation number corresponds to the number in the illustration to indicate removal steps.
- Disassembly steps :
The part designation number corresponds to the number in the illustration to indicate disassembly steps.

- Installation steps :
Specified in case installation is impossible in reverse order of removal steps. Omitted if installation is possible in reverse order of removal steps.
- Reassembly steps :
Specified in case installation is impossible in reverse order of removal steps. Omitted if reassembly is possible in reverse order of disassembly steps.

Classifications of major maintenance / service points

When there are major points relative to maintenance and servicing procedures (such as essential maintenance and service points, maintenance and service standard values, information regarding the use of special tools, etc.). These are arranged together as major maintenance and service points and explained in detail.

<<A>> : Indicates that there are essential points for removal or disassembly.


>>A<< : Indicates that there are essential points for installation or reassembly.

**BASIC BRAKE SYSTEM
FRONT DISC BRAKE ASSEMBLY** **35A-21**

INSTALLATION SERVICE POINTS


>>A<< **BRAKE HOSE INSTALLATION**

1. Install the brake hose end on the bracket and another end on the front brake assembly.



2. Twist the brake hose towards the lesser torsion between the brake hose and bracket as shown and secure it to the bracket.

>>B<< **BRAKE CALIPER ASSEMBLY INSTALLATION**




1. In order to measure the brake drag torque, measure the hub torque with the pads removed by the following procedure.

- (1) Use a spring balance to measure the hub torque in the forward direction.
- (2) Record hub torque with pads removed.

CAUTION
Do not let any oil, grease or other contamination get onto the friction surfaces of the pads and brake discs.

2. After re-installing the caliper support to the knuckle, install the pad clips and the pads to the caliper support.




3. Clean the piston and insert into cylinder with special tool disc brake piston expander (MB990520).

4. Install the pad clips and the pads to the caliper support and tighten the pin bolt to the specified torque.

Tightening torque : 38 ± 4 N·m

Operating procedures, cautions, etc. on removal, installation, disassembly and reassembly are described

LUBRICATION POINTS



CAUTION
The piston seal inside the caliper seal kit is coated with a special grease. Do not wipe this grease off.

Brake fluid: DOT 3 or DOT 4






Grease: Repair kit grease

The title of the page (following the page on which the diagram of component parts is presented) indicating the locations of lubrication and sealing procedures.

Indicates (by symbols) where lubrication is necessary.

Symbols for lubrication, sealants and adhesives

Symbols are used to show the locations for lubrication and for application of sealants and adhesives. These symbols are included in the diagram of component parts or on the page following the component parts page. The symbols do not always have accompanying text to support that symbol.

-  : Grease (Multi-purpose grease unless there is a brand or type specified)
-  : Sealant or adhesive
-  : Automatic transmission fluid, brake fluid, power steering fluid or air conditioning compressor oil
-  : Engine oil or gear oil
-  : Adhesive tape or butyl rubber tape

TROUBLESHOOTING GUIDELINES

M1001008800287

VERIFY THE COMPLAINT

- Make sure the customer's complaint and the service writer's work order description are understood before starting work.
- Make sure the correct operation of the system is understood. Read the service manual description to verify normal system operation.
- Operate the system to see the symptoms. Look for other symptoms that were not reported by the customer, or on the work order, that may be related to the problem.

DETERMINE POSSIBLE CAUSES

Compare the confirmed symptoms to the diagnostic symptom indexes to find the right diagnosis procedure.

If the confirmed symptoms cannot be found on any symptom index, determine other possible causes.

- Analyze the system diagrams and list all possible causes for the problem symptoms.
- Rank all these possible causes in order of probability, based on how much of the system they cover, how likely they are to be the cause, and how easy they will be to check. Be sure to take experience into account. Consider the causes of similar problems seen in the past. The list of causes should be ranked in order from general to specific, from most-likely to least-likely, and from easy-to-check to hard-to-check.

FIND THE PROBLEM

After the symptoms have been confirmed, and probable causes have been identified, the next step is to make step-by-step checks of the suspected system components, junctions, and links in logical order.

Use the diagnostic procedures in the service manual whenever possible. Follow these procedures carefully to avoid missing an important step in the diagnosis sequence. It might be the skipped step that leads to the solution of the problem.

If the service manual doesn't have step-by-step procedures to help diagnose the problem, make a series of checks based on the ranked list of probable causes. Troubleshooting checks should be made in the order that the list of causes was ranked:

- General to specific
- Most-likely to least-likely
- Easy-to-check to hard-to-check

REPAIR THE PROBLEM

When the step-by-step troubleshooting checks find a fault, perform the proper repairs. Make sure to fix the root cause of the problem, not just the symptom. Just fixing the symptom, without fixing the root cause, will cause the symptom to eventually return.

VERIFY THE REPAIR

After repairs are made, recheck the operation of the system to confirm that the problem is eliminated. Be sure to check the system thoroughly. Sometimes new problems are revealed after repairs have been made.

HOW TO USE TROUBLESHOOTING/INSPECTION SERVICE POINTS

TROUBLESHOOTING CONTENTS

Troubleshooting of electronic control systems for which the scan tool can be used follows the basic outline described below. Even in systems for which the scan tool cannot be used, part of these systems still follow this outline.

1. STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING

Troubleshooting strategy is shown in each group.

2. SYSTEM OPERATION AND SYMPTOM VERIFICATION TESTS

If verification of the symptom(s) is difficult, procedures for checking operation and verifying symptoms are shown.

3. DIAGNOSTIC FUNCTION

The following trouble code diagnosis are shown.

- How to read diagnostic trouble codes
- How to erase diagnostic trouble codes
- Input inspection service points

M1001013300103

4. DIAGNOSTIC TROUBLE CODE CHART

If the scan tool displays a diagnostic trouble code, find the applicable inspection procedure according to this chart.

5. SYMPTOM CHART

If there are symptoms, even though the scan tools show that no DTCs are set, inspection procedures for each symptom will be found by using this chart.

6. DIAGNOSTIC TROUBLE CODE PROCEDURES

Indicates the inspection procedures corresponding to each diagnostic trouble code. (Refer to P.00-8).

7. SYMPTOM PROCEDURES

Indicates the inspection procedures corresponding to each symptom listed in the Symptom Chart. (Refer to P.00-8).

8. SERVICE DATA REFERENCE TABLE

Inspection items and normal judgement values have been provided in this chart as reference information.

9. CHECK AT ECU TERMINALS

Terminal numbers for the ECU connectors, inspection items, and standard values have been provided in this chart as reference information.

TERMINAL VOLTAGE CHECKS

1. Connect a needle-nosed wire probe to a voltmeter probe.

CAUTION

Short-circuiting the positive (+) probe between a connector terminal and ground could damage the vehicle wiring, the sensor, the ECU, or all three. Use care to prevent this!

2. Insert the needle-nosed wire probe into each of the ECU connector terminals from the wire side, and measure the voltage while referring to the check chart.

NOTE: Measure voltage with the ECU connectors connected.

You may find it convenient to pull out the ECU to make it easier to reach the connector terminals. Checks don't have to be carried out in the order given in the chart.

3. If voltage readings differ from normal condition values, check related sensors, actuators, and wiring. Replace or repair as needed.
4. After repair or replacement, recheck with the voltmeter to confirm that the repair has corrected the problem.

TERMINAL RESISTANCE AND CONTINUITY CHECKS

1. Turn the ignition switch to the "LOCK" (OFF) position.
2. Disconnect the ECU connector.

CAUTION

If resistance and continuity checks are performed on the wrong terminals, damage to the vehicle wiring, sensors, ECU, and/or ohmmeter may occur. Use care to prevent this!


3. Measure the resistance and check for continuity between the terminals of the ECU harness-side connector while referring to the check chart.
NOTE: Checks don't have to be carried out in the order given in the chart.
4. If the ohmmeter shows any deviation from the Normal Condition value, check the corresponding sensor, actuator and related electrical wiring, then repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair has corrected the problem.

10. INSPECTION PROCEDURES USING AN OSCILLOSCOPE

When there are inspection procedures using an oscilloscope, these are listed.

HOW TO USE THE INSPECTION PROCEDURES

The causes of many of the problems occurring in electric circuitry are generally the connectors, components, the ECU, and the harnesses between connectors, in that order. These inspection procedures follow this order. They first try to discover a problem with a connector or a defective component.



(5) Explains about technical details.

TECHNICAL DESCRIPTION

- The engine coolant temperature sensor converts the engine coolant temperature to a voltage and output it.

DTC SET CONDITIONS

Check Conditions

- Engine coolant temperature was 7°C (45°F) or more immediately before the engine was stopped at the last drive.

(6) Describes the conditions for that DTC being set (stored).

- The PCM checks whether this voltage is within a specified range.

(7) Describes possible cause(s) for that DTC.

TROUBLESHOOTING HINTS (The most likely causes for this code to be set are:)

- Engine coolant temperature sensor failed.
- Open or shorted engine coolant temperature sensor circuit, or loose connector.
- PCM failed.

(8) Start of the diagnosis procedure for that DTC.

DIAGNOSIS

Required special tool:

- MB991958: Scan Tool (MUT-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: USB Cable
 - MB991910: Main Harness A

(9) Identifies the special tool(s) necessary for diagnosing that DTC.

STEP 1. Using scan tool MB991958, check data list item 15: Transmission Fluid Temperature Sensor.

CAUTION
 To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- Connect scan tool MB991958 to the data link connector.
- Start the engine.
- Set scan tool MB991958 to the data reading mode for item 15, Transmission Fluid Temperature Sensor.
 - When the engine is cool: Almost equal to the ambient temperature (atmospheric temperature)
- Turn the ignition switch to the "LOCK" (OFF) position.

NOTE: Set scan tool MB991958 to data reading mode for item number 13, Intake Air Temperature (IAT) Sensor and note the temperature measurement. When the engine is cool, the temperature should be almost equal to the ambient temperature (atmospheric temperature), and the IAT sensor measurement should be approximately the same as the Transmission Fluid Temperature Sensor.

- When the engine is warm: 70 to 80°C (158 to 176°F)

(4) Turn the ignition switch to the "LOCK" (OFF) position.

Q: Is the sensor operating properly?

YES : It can be assumed that this malfunction is intermittent. Refer to GROUP 00, How to Use Troubleshooting/ Inspection Service Points – How to Cope with Intermittent Malfunction .

NO : Go to Step 2.

(10) Provides the inspection procedure for that DTC step by step.

AC210616 AD

HARNESS INSPECTION

Check for an open or short circuit in the harness between the terminals which were faulty according to the connector measurements. Carry out this inspection while referring to GROUP 00E, Harness Connector Inspection P.00E-2. Here, "Check harness between power supply and terminal xx" also includes checking for blown fuse. For inspection service points when there is a blown fuse, refer to "Inspection Service Points for a Blown Fuse P.00-15."

MEASURES TO TAKE AFTER REPLACING THE ECU

If the trouble symptoms have not disappeared even after replacing the ECU, repeat the inspection procedure from the beginning.


CONNECTOR MEASUREMENT SERVICE POINTS

M1001013600610

Turn the ignition switch to the "LOCK" (OFF) position when connecting and disconnecting the connectors. Turn the ignition switch to "ON" when measuring, unless there are instructions to the contrary.

IF INSPECTING WITH THE CONNECTOR CONNECTED <WATERPROOF CONNECTORS>

Be sure to use special tool. Never insert a test probe from the harness side, as this will reduce the waterproof performance and result in corrosion.




IF INSPECTING WITH THE CONNECTOR CONNECTED <ORDINARY (NON-WATERPROOF) CONNECTORS>

Required Special Tool:

- MB992006: Extra Fine Probe

Inspect by inserting a test probe from the harness side. If the connector is too small to insert a test probe (e.g. control unit connector), do not insert it forcibly. Use special tool MB992006 (extra fine probe).



IF INSPECTING WITH THE CONNECTOR DISCONNECTED



<When Inspecting a Female Pin>

- From front side of the connector

Required Special Tool:

MB991219: Inspection Harness (Included in MB991223, Harness Set)

The inspection harness for connector pin contact pressure should be used. The test probe should never be forcibly inserted, as it may cause a defective contact.



- From back side of the connector (SRS-ECU harness side connector)
Since the SRS-ECU harness connector is plated to improve conductivity, observe the warning below when checking this connector.

⚠ WARNING


Insert the backprobing tool into the connector from the harness side, and connect the tester to the backprobing tool. If any tool other than the backprobing tool is used, it may cause damage to the harness and other components. Furthermore, measurement should not be carried out by touching the backprobing tool directly against the terminals from the front of the connector. The terminals are plated to increase their conductivity, so that if they are touched directly by the backprobing tool, the plating may break, which will decrease reliability.

<When Inspecting a Male Pin>

⚠ CAUTION

At this time, be careful not to short the connector pins with the test probes. Doing so may damage the circuits inside the ECU.

Touch the pin directly with the test probe.




CONNECTOR INSPECTION SERVICE POINTS


M1001013700424

VISUAL INSPECTION

- Connector is disconnected or improperly connected
- Connector pins are pulled out
- Stretched or broken wires at terminal section
- Low contact pressure between male and female terminals
- Low connection pressure due to rusted terminals or foreign matter lodged in terminals

**CONNECTOR PIN INSPECTION**

If the connector pin stopper is damaged, the terminal connections (male and female pins) will not be perfect even when the connector body is connected, because the pins may pull out of the back side of the connector. Therefore, gently pull the wires one by one to make sure that no pins pull out of the connector.




CONNECTOR ENGAGEMENT INSPECTION

Required Special Tool:

MB991219: Inspection Harness (contained in MB991223 Test Harness)

Use special tool, MB991219 to inspect the engagement of the male pins and female pins. [Pin drawing force: 1 N (0.2 pound) or more]



HOW TO COPE WITH INTERMITTENT MALFUNCTIONS

M1001013900105

Most intermittent malfunctions occur under certain conditions. If those conditions can be identified, the cause will be easier to find.

TO COPE WITH INTERMITTENT MALFUNCTION; 1. ASK THE CUSTOMER ABOUT THE MALFUNCTION

Ask what it feels like, what it sounds like, etc. Then ask about driving conditions, weather, frequency of occurrence, and so on.

2. DETERMINE THE CONDITIONS FROM THE CUSTOMER'S RESPONSES

Typically, almost all intermittent malfunctions occur from conditions like vibration, temperature and/or moisture change, poor connections. From the customer's responses, it should be reasoned which condition is most likely.

3. USE SIMULATION TEST

Use the simulation tests below to attempt to duplicate the customer's complaint. Determine the most likely circuit(s) and perform the simulation tests on the connectors and parts of that circuit(s). Be sure to use the inspection procedures provided for diagnostic trouble codes and trouble symptoms.

For temperature and/or moisture condition related intermittent malfunctions, try to change the conditions of the suspected circuit components, then use the simulation tests below.

4. VERIFY THE INTERMITTENT MALFUNCTION IS ELIMINATED


Repair the malfunctioning part and try to duplicate the condition(s) again to verify the intermittent malfunction has been eliminated.

SIMULATION TESTS

NOTE: In case of difficulty in finding the cause of the intermittent malfunction, the data recorder function in the scan tool is effective.

For these simulation tests, shake, then gently bend, pull, and twist the wiring of each of these examples to duplicate the intermittent malfunction.

- Shake the connector up-and-down, and right-and-left.
- Shake the wiring harness up-and-down, and right-and-left. Especially, check the splice points of wiring harnesses carefully. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).
- Shake the part or sensor.



HOW TO TREAT PAST TROUBLE

M1001014100384

Since the trouble may still be present even the status is "Stored", set the vehicle to the diagnostic trouble code detection condition and check that the status changes to "Active". If the status does not change from "Stored", carry out the following procedure.

1. Establish from the customer whether a fuse or connector has been replaced or disconnected.
2. If yes, erase the diagnostic trouble code, and then check that no diagnostic code is reset. If no diagnostic trouble code is reset, the diagnosis is complete.
3. If no, follow the applicable Diagnostic Trouble Code Chart. Then check the wiring harness and connector, and refer to "How to Cope with Intermittent Malfunction P.00-13 ."


INSPECTION SERVICE POINTS FOR A BLOWN FUSE

M1001013800409

Remove the blown fuse and measure the resistance between the load side of the blown fuse and the ground. Close the switches of all circuits which are connected to this fuse. If the resistance is almost 0Ω at this time, there is a short somewhere between these switches and the load. If the resistance is not 0Ω , there is no short at the present time, but a momentary short has probably caused the fuse to blow.

The main causes of a short circuit are the following.

- Harness being clamped by the vehicle body
- Damage to the outer casing of the harness due to wear or heat
- Water getting into the connector or circuitry
- Human error (mistakenly shorting a circuit, etc.)





VEHICLE IDENTIFICATION**VEHICLE IDENTIFICATION NUMBER PLATE**

M1001005501116

VEHICLES IDENTIFICATION NUMBER LOCATION

The vehicle identification number (VIN) plate is located on a plate attached to the left top side of the instrument panel.

**CODE CHART**

No.	Item	Content	
1	Country	J	Japan
2	Make	A	Mitsubishi motors corporation
3	Vehicle type	3	Passenger car
4	Others	2	Air bags (driver, passenger, side curtain, driver knee)
5	Line	X	MITSUBISHI LANCER SPORTBACK (FWD)
		Y	MITSUBISHI LANCER SPORTBACK (AWD)
6	Price class	8	SPORTS
		6	SPECIAL
7	Body	H	5 door hatch back
8	Engine	V	2.0L DOHC Charge air cooler turbocharger (4B11) MIVEC
		W	2.4L DOHC (4B12) MIVEC
9	Check digits*	0, 1, 2, 3, -----9, X	
10	Model year	A	2010 year
11	Plant	U	Mizushima
12	Serial number	000001 to 999999	

NOTE: *: Check digit means a single number, or letter X, used to verify the accuracy of transcription of vehicle identification number.

VEHICLE IDENTIFICATION NUMBER LIST

VEHICLES FOR USA

(VEHICLES FOR FEDERAL EMISSION REGULATION)

VIN (Except serial number)	Model code		Engine model	Transaxle model	Fuel system
JA32Y6HV_AU	CX4AL	MUFZL2M	4B11 DOHC MIVEC with Charge air cooler turbocharger [1,998 cm ³ (121.9 cu in)] gasoline engine	W6DGA [AWD, Twin Clutch-Sportronic Shift Transmission (TC-SST)]	MFI
JA32X8HW_AU	CX5AL	NXHL2M	4B12 DOHC MIVEC [2,360 cm ³ (144.0 cu in)] gasoline engine	F5MBB (FWD, 5 M/T)	
		TXHL2M		F1CJA (FWD, INVECS-III CVT) with sport mode	

(VEHICLES FOR CALIFORNIA EMISSION REGULATION)

VIN (Except serial number)	Model code		Engine model	Transaxle model	Fuel system
JA32X8HW_AU	CX5AL	NXHL7M	4B12 DOHC MIVEC [2,360 cm ³ (144.0 cu in)] gasoline engine	F5MBB (FWD, 5 M/T)	MFI
		TXHL7M		F1CJA (FWD, INVECS-III CVT) with sport mode	

VEHICLES FOR PUERTO RICO

VIN (Except serial number)	Model code		Engine model	Transaxle model	Fuel system
JA32X8HW_AU	CX5AL	NXHL2M	4B12 DOHC MIVEC [2,360 cm ³ (144.0 cu in)] gasoline engine	F5MBB (FWD, 5 M/T)	MFI
		TXHL2M		F1CJA (FWD, INVECS-III CVT) with sport mode	

VEHICLES FOR GUAM AND SAIPAN

VIN (Except serial number)	Model code		Engine model	Transaxle model	Fuel system
JA32Y6HV_AU	CX4AL	MUFZL2M	4B11 DOHC MIVEC with Charge air cooler turbocharger [1,998 cm ³ (121.9 cu in)] gasoline engine	W6DGA [AWD, Twin Clutch-Sportronic Shift Transmission (TC-SST)]	MFI
JA32X8HW_AU	CX5AL	NXHL2M	4B12 DOHC MIVEC [2,360 cm ³ (144.0 cu in)] gasoline engine	F5MBB (FWD, 5 M/T)	
		TXHL2M		F1CJA (FWD, INVECS-III CVT) with sport mode	


VEHICLES FOR CANADA

VIN (Except serial number)	Model code		Engine model	Transaxle model	Fuel system
JA32Y6HV_AU	CX4AL	MUFZL3M	4B11 DOHC MIVEC with Charge air cooler turbocharger [1,998 cm ³ (121.9 cu in)] gasoline engine	W6DGA [AWD, Twin Clutch-Sportronic Shift Transmission (TC-SST)]	MFI
JA32X8HW_AU	CX5AL	NXHL3M	4B12 DOHC MIVEC [2,360 cm ³ (144.0 cu in)] gasoline engine	F5MBB (FWD, 5 M/T)	
		TXHL3M		F1CJA (FWD, INVECS-III CVT) with sport mode	

CHASSIS NUMBER

M1001005601458

The chassis number is stamped on the front floor pan.



CHASSIS NUMBER CODE CHART

Chassis number code	Example	Content
CX5AAU00001	CX5A	MITSUBISHI LANCER SPORTBACK
	AU000001	Refer to 10th thru 17th digits of VIN plate

VEHICLE INFORMATION CODE PLATE


M1001005402651

The vehicle information code plate is riveted to the face of the passenger's door sill.

CODE CHART

No.	Item	Example	Content
1	MODEL	CX5AL	Vehicle model
		NXHL2M	Model series
2	ENGINE	4B12	Engine model
3	EXT	W37A	Exterior code
4	TRANS AXLE	F5MBB	Transaxle model
5	COLOR	W37	Body color code
6	INT	04X	Interior code
7	OPT	ZP6	Equipment code


For monotone color vehicles, the body color code shall be indicated.



TIRE AND LOADING INFORMATION PLACARD

M1001015800267

The tire and loading information placard is located on the inside sill of the driver's door.



ENGINE MODEL STAMPING


M1001005700689

The engine model is stamped on the cylinder block. These engine model numbers are as shown as follows.

Engine model	Engine displacement
4B11	2.0L
4B12	2.4L

The engine serial number is stamped near the engine model number.


Engine number	AA0201 to YY9999
---------------	------------------



GENERAL DATA AND SPECIFICATIONS

M1001000904691


<2.0L ENGINE>



AC807869

Item		CX4AL	
		MUFZL2M/3M	
Vehicle dimension mm (in)	Overall width	1	1,760 (69.4)
	Tread-front	2	1,530 (60.2)
	Overall length	3	4,585 (180.4)
	Overhang-front	4	955 (37.6)
	Wheelbase	5	2,635 (103.7)
	Overhang-rear	6	995 (39.1)
	Ground clearance	7	147 (5.8)
	Overall height (unladen)	8	1,515 (59.7)
	Tread-rear	9	1,530 (60.2)
Vehicle weight kg (lb)	Curb weight	1,620 (3,572)	
	Gross vehicle weight rating	2,045 (4,509)	
	Gross axle weight rating-front	1,080 (2,381)	
	Gross axle weight rating-rear	1,015 (2,238)	
Seating capacity		5	
Engine	Model code	4B11 with Charge air cooler turbocharger	
	Piston displacement cm ³ (cu in)	1,998 (121.9)	
	Maximum output kW/r/min (HP/r/min)	177/6,000 (237/6,000)	
	Maximum torque N·m/r/min (ft-lb/r/min)	343/2,500-4,750 (253/2,500-4,750)	
Fuel system	Fuel supply system	MFI	
Transaxle	Model code	W6DGA	
	Type	TC-SST	
Minimum turning radius m (ft)		5.0 (16.4)	

<2.4L ENGINE>



AC807381AB

Item		CX5AL		
		NXHL2M/3M/7M	TXHL2M/3M/7M	
Vehicle dimension mm (in)	Overall width	1	1,760 (69.4)	1,760 (69.4)
	Tread-front	2	1,530 (60.2)	1,530 (60.2)
	Overall length	3	4,585 (180.4)	4,585 (180.4)
	Overhang-front	4	955 (37.6)	955 (37.6)
	Wheelbase	5	2,635 (103.7)	2,635 (103.7)
	Overhang-rear	6	995 (39.1)	995 (39.1)
	Ground clearance	7	147 (5.8)	147 (5.8)
	Overall height (unladen)	8	1,515 (59.7)	1,515 (59.7)
	Tread-rear	9	1,530 (60.2)	1,530 (60.2)
Vehicle weight kg (lb)	Curb weight		1,405 (3,098)	1,435 (3,164)
	Gross vehicle weight rating		1,900 (4,190)	1,900 (4,190)
	Gross axle weight rating-front		1,010 (2,227)	1,010 (2,227)
	Gross axle weight rating-rear		960 (2,117)	960 (2,117)
Seating capacity			5	5
Engine	Model code		4B12	4B12
	Piston displacement cm ³ (cu in)		2,360 (144.0)	2,360 (144.0)
	Maximum output kW/r/min (HP/r/min)		125/6,000 (168/6,000) <Except California>, 120/6,000 (161/6,000) <California>	
	Maximum torque N·m/r/min (ft-lb/r/min)		226/4,100 (167/4,100) <Except California>, 218/4,100 (161/4,100) <California>	
Fuel system	Fuel supply system		MFI	MFI
Transaxle	Model code		F5MBB	F1CJA
	Type		5 M/T	CVT
Minimum turning radius m (ft)			5.0 (16.4)	5.0 (16.4)

PRECAUTIONS BEFORE SERVICE

CAUTIONS FOR WORKING IN ENGINE COMPARTMENT <2.0 L ENGINE>

M1001016800130

⚠ WARNING

Just after the ignition switch is turned to "LOCK" (OFF) position, the adjustments must always be made with the cooling fan stopped. After the ignition switch is turned to "LOCK" (OFF) position, the cooling fan might be driven for a few minutes by the after run fan control. If the adjustments are made with the cooling fan driven, injury or damage may occur.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

M1001011601510

1. Items to review when servicing SRS:
 - (1) Be sure to read GROUP 52B, Supplemental Restraint System (SRS). For safe operation, please follow the directions and heed all warnings.
 - (2) Wait at least 60 seconds after disconnecting the battery cable before doing any further work. The SRS system is designed to retain enough voltage to deploy the air bag even after the battery has been disconnected. Serious injury may result from unintended air bag deployment if work is done on the SRS system immediately after the battery cable is disconnected.
 - (3) Warning labels must be heeded when servicing or handling SRS components. Warning labels can be found in the following locations.
 - Air bag module (Driver's or front passenger's)
 - SRS-ECU
 - Knee air bag module
 - Sunvisor
 - Seat belt with pre-tensioner
 - Side-airbag module (Driver's side and front passenger's side)
 - Curtain air bag module (Driver's side and front passenger's side)
 - Center pillar (Driver's side and front passenger's side)
 - Glove box
 - (4) Always use the designated special tools and test equipment.
 - (5) Store components removed from the SRS in a clean and dry place. The air bag module should be stored on a flat surface and placed so that the pad surface is facing upward.
 - (6) Never attempt to disassemble or repair the SRS components (SRS-ECU, air bag module and clock spring). If there is a defect, replace the defective part.
 - (7) Whenever you finish servicing the SRS, check the SRS warning light operation to make sure that the system functions properly.
 - (8) Be sure to deploy the air bag before disposing of the air bag module or disposing of a vehicle equipped with an air bag (Refer to GROUP 52B [P.52B-454](#), Air Bag Module Disposal Procedures).
2. Observe the following when carrying out operations on places where SRS components are installed, including operations not directly related to the SRS air bag.
 - (1) When removing or installing parts, do not allow any impact or shock to occur to the SRS components.
 - (2) If heat damage may occur during paint work, remove the SRS-ECU, the air bag module, clock spring, the front impact sensor, the side impact sensor, and the seat belt pre-tensioner.
 - SRS-ECU, air bag module, clock spring, front impact sensor, the side impact sensor: 93 °C (199 °F) or more
 - Seat belt pre-tensioner: 90 °C (194 °F) or more

**SCAN TOOL (MULTI USE TESTER { M.U.T.-III }
SUB ASSEMBLY)**


M1001012400226

⚠ CAUTION

Turn the ignition switch to the "LOCK" (OFF) position before disconnecting or connecting the scan tool.


NOTE: M.U.T.-III trigger harness is not necessary when pushing V.C.I. ENTER key.

VEHICLE COMMUNICATION
INTERFACE (V.C.I.)




MB991824

M.U.T.-III USB CABLE



MB991827


M.U.T.-III MAIN HARNESS A



MB991910

M.U.T.-III MAIN HARNESS B


DO NOT USE



MB991911


M.U.T.-III MAIN HARNESS C

DO NOT USE




MB991914

M.U.T.-III MEASUREMENT ADAPTER



MB991825

M.U.T.-III TRIGGER HARNESS



MB991826

AC21088AD

HOW TO PERFORM VEHICLE IDENTIFICATION NUMBER (VIN) WRITING

M1001011400609

CAUTION


The F.A.S.T-Key (Free-hand Advanced Security Transmitter) is described as the Keyless Operation System (KOS) in this manual. (KOS is indicated as F.A.S.T. in the scan tool display.)

Follow the procedure below to register the VIN of the Wireless Control Module (WCM) and the Keyless Operation System (KOS).


The VIN is stored in the engine control module (ECM), WCM, and the KOS-ECU. If the VIN is improperly erased, the engine warning light or the keyless operation system warning indicator illuminate, and the diagnostic trouble code is displayed. When the ECM, WCM, and the KOS-ECU are replaced, follow the procedure below to write the VIN.

Screen flow of scan tool (M.U.T.- III)

<When ECM is replaced>



<When WCM or KOS-ECU are replaced>



AC700593 AE

WRITING PROCEDURE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

⚠ CAUTION

Check that diagnostic trouble code P0603 "EEPROM fail" is not set. When diagnostic trouble code P0603 "EEPROM fail" is set, the ECM cannot store the key code even if the key code is registered. If this diagnostic trouble code is set, troubleshoot the ECM and repair. Then register the key code to the ECM.

⚠ CAUTION



Before connecting or disconnecting the MB991958: Scan Tool, turn the ignition switch to the "LOCK" (OFF) position. Connect scan tool MB991958 to the 16-pin data link connector as follows.

NOTE: For details on how to use scan tool MB991958, refer to the "M.U.T.-III Owner's Manual."


1. Ensure that the ignition switch is at the "LOCK" (OFF) position.
2. Start up the personal computer.
3. Connect special tool MB991827 to special tool MB991824 and the personal computer.
4. Connect special tool MB991910 to the special tool MB991824.
5. Connect special tool MB991910 to the data link connector of the vehicle.
6. Turn the special tool MB991824 power switch to the "ON" position.

NOTE: When the special tool MB991824 is energized, the special tool MB991824 indicator light will be illuminated in a green color.

7. Start the "M.U.T.-III system" on the personal computer and turn the ignition switch to the "ON" position.
8. Select "F.A.S.T./IMMO/Keyless/TPMS" button from the "System Select" screen. Then, select the applicable option code item and push the OK button.
9. Select "Special Function" on the next screen.





Option: When IMMOBI & F.A.S.T. & TPMS is selected




10. Select "ENG key code & VIN Reg." from the "Special Function" screen.


Option: When IMMOBI & Keyless & TPMS is selected



11. Push the OK button after "ENG key code & VIN Reg." is displayed.
12. Push the OK button after "Completed. Press the OK button and move to VIN writing function." is displayed.



13. Enter the VIN of registering vehicle and push the OK button.
14. Push the OK button after "VIN Writing will start. Are you sure?" is displayed.
15. Return to the previous screen and "In Progress" is displayed at the lower-left corner on the screen.
16. Push the OK button after "Completed." is displayed.



17. VIN writing result is displayed.
18. Complete the scan tool MB991958.
19. Disconnecting the scan tool MB991958 is the reverse of the connecting sequence, making sure that the ignition switch is at the "LOCK" (OFF).
20. Push the OK button after "Completed." is displayed.
21. Terminate the scan tool MB991958.
22. Turn the ignition switch to the "LOCK" (OFF) position and then disconnect scan tool MB991958.

VIN WRITING STEPS FOR WCM AND KOS-ECU

⚠ CAUTION

Before the VIN registration to WCM and KOS-ECU, check that the VIN of ECM and vehicle are matched.

⚠ CAUTION

Check that diagnostic trouble code B2416 "ECU internal error" is not set. When diagnostic trouble code B2416 "ECU internal error" is set, the WCM and the KOS-ECU cannot store the VIN even if the VIN is written. If this diagnostic trouble code is set, troubleshoot the WCM or the KOS-ECU and repair. Then write the VIN to the WCM or the KOS-ECU.

⚠ CAUTION



Before connecting or disconnecting the MB991958: Scan Tool, turn the ignition switch to the "LOCK" (OFF) position. Connect scan tool MB991958 to the 16-pin data link connector as follows.


NOTE: For details on how to use scan tool MB991958, refer to the "M.U.T.-III Owner's Manual."

1. Ensure that the ignition switch is at the "LOCK" (OFF) position.
2. Start up the personal computer.
3. Connect special tool MB991827 to special tool MB991824 and the personal computer.
4. Connect special tool MB991910 to the special tool MB991824.
5. Connect special tool MB991910 to the data link connector of the vehicle.
6. Turn the special tool MB991824 power switch to the "ON" position.


NOTE: When the special tool MB991824 is energized, the special tool MB991824 indicator light will be illuminated in a green color.

7. Start the "M.U.T.-III system" on the personal computer and turn the ignition switch to the "ON" position.
8. Select "F.A.S.T./IMMO/Keyless/TPMS" button from the "System Select" screen. Then, select the applicable option code item and push the OK button.
9. Select "Coding" on the next screen.






10. Select "VIN Writing" on "Coding" screen.



11. Push the OK button after the VIN written in the engine control module is displayed.

12. Push the OK button after "VIN Writing will start. Are you sure?" is displayed.

13. Push the OK button after "Completed." is displayed.



14. Result of VIN writing is displayed.

15. Register the other ID code. (Refer to GROUP 42B, Troubleshooting –ID Code Registration Judgment Table [P.42B-11](#) <Vehicles with KOS> or GROUP 42C, Troubleshooting –ID Code Registration Judgment Table [P.42C-10](#) <Vehicles with WCM>.)

CODING LIST

M1001015000904

CAUTION

With the ETACS functions being customized, if any of the ETACS-ECU variant coding and option coding items are changed, the customized contents are reset. In such case, the functions need to be recustomized.

Before troubleshooting, check that the coding data written into the engine control module, TC-SST-ECU and ETACS-ECU are normal. If they are not the same as the initial settings, various functions and systems will not work correctly.

VARIANT CODING

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: Vehicle Communication Interface (V.C.I.)
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A (Vehicles with CAN communication system)

The coding data can be checked by operating scan tool MB991958.

NOTE: For details on how to use the scan tool MB991958, refer to the "M.U.T.-III Owner's manual".

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

1. Ensure that the ignition switch is at the "LOCK" (OFF) position.
2. Start up the personal computer.
3. Connect special tool MB991827 to special tool MB991824 and the personal computer.
4. Connect special tool MB991910 to special tool MB991824.
5. Connect special tool MB991910 to the data link connector.
6. Turn the power switch of special tool MB991824 to the "ON" position.

NOTE: When special tool MB991824 is energized, special tool MB991824 indicator light will be illuminated in a green color.

7. Start the "M.U.T.-III system" on the personal computer.
8. Turn the ignition switch to the "ON" position.
9. Select "System select" from the start-up screen.
10. Select "From 2006 MY" under "Model Year". Check that "Vehicle Information" contents are correct.
11. On the system list screen, select "MPI/GDI/DIESEL" to check the engine control module data, "AT/CVT/A-MT/TC-SST" to check the TC-SST data, and "ETACS" to check the ETACS-ECU data.

NOTE: If "Loading Option Setup" list is shown, click appropriate box.


12. Select "Coding."
13. Select "Coding information & copy."

⚠ CAUTION

Refer to the scan tool (M.U.T.-III) operation manual, and perform coding.

14. If the displayed coding information is different from the corresponding initial setting in the list, replace the ECU with a correctly coded one. For replacement of the engine control module, refer to GROUP 13A, engine control module [P.13A-895](#) <4B11> or GROUP 13B, engine control module [P.13B-1022](#) <4B12>. For replacement of the TC-SST-ECU*, refer to GROUP 22C, Transaxle Assembly [P.22C-497](#). For replacement of the ETACS-ECU, refer to GROUP 54A, ETACS [P.54A-769](#).

*NOTE: *: TC-SST-ECU cannot be disassembled. Thus, replace the transaxle assembly.*



ENGINE CONTROL MODULE CODING DATA LIST

Item name	Initial value
Final gear ratio	5MT/6MT <M/T>
	6.120 <CVT>
	4.062 <TC-SST>
Tire circumference	2015mm
IMMOBILIZER	Present
ABS	Not present
A.S.C.	Present
S/W variation	Variation No.1

TC-SST-ECU CODING DATA LIST

Item name	Initial value
Vehicle line	LANCER H/B
Destination	U.S.
Tire size	215/45R18
Cruise control	Present
A.S.C.	Present
Turbo charger	T/C (INCONEL-AL)

ETACS-ECU CODING DATA LIST

NOTE: The items to be displayed may differ depending on the version of the ETACS-ECU.

Item name	Initial value
Vehicle line	LANCER H/B
Model year	(Displays the model year)
SST oil cooling fan	Not present
Destination	U.S.
Transaxle	5MT <M/T>
	CVT <CVT>
	TC-SST <TC-SST>
Engine type	2.0L D4 VVT T/C <4B11>
	2.4L D4 MPI VVT <4B12>
Engine power	Normal
Handle side	LHD
Chassis Type for A.S.C.	Type 6 <4B11>
	Type 4 <4B12>
OSS	Not present
Final drive	Front Drive <4B12>
	AWD FF Base <4B11>
Transfer	2WD <4B12>
	ACD <4B11>
IG off delay control	Disabled <4B12>
	Enable <4B11>
Dead lock operation customize	Disabled
After wipe customize	Enabled(def.D)
Tire circumference	2015mm
Fuel tank	Not used
DRL ^{*1} type	Dimming DRL w/ P <halogen type>
	Independent DRL/P <discharge type>
Smart entry system	Not present or Type A or Type C
TPMS ^{*1}	Present
Keyless entry ^{*2}	Present
Airbag Auto Hazard	Not Present
Immobilizer	Type A or Type B
Cruise control	Present
Corner sensor	Not present

Item name	Initial value
Headlight auto leveling device	Not present
Oil level warning	Not present
Water separate warning	Not present
Speed meter scale	Not used
Idle neutral control	Not present
Theft alarm sensor	Not present
T/M oil cooler	Not present or Present(A)
Theft sensor gain setting	Type 1
Side air bag	Present
ACC power auto cut	Default enabled
Number of speaker* ²	Premium or 6 speakers
Seat material* ²	Fabric or Leather
Auto light control	No/Cng Ng or Hi RLS/Chg Ng
Front differential	Open <4B12>
	Helical <4B11>
Rear differential	Undefined <4B12>
	LOM <4B11>
Power window type	Type P4
Sunroof type	Not present or Type S4
WCM	Present
OCM	Present
ORC	Present
A/C	Present
AUDIO* ²	Not present or Present
AND* ²	Not present or Present
Siren answer	Disabled
Theft alarm siren	Not present
CAMERA	Not present
Corner sensor control unit	Not present
Electric Slide door (Left)	Not present
Electric Slide door (Right)	Not present
ETG	Not present
ESS ECU	Not present
HFM* ²	Not present or Present
Intelligent washer customize	Enabled(def.E)

**GENERAL
PRECAUTIONS BEFORE SERVICE**

00-33

Item name	Initial value
Headlight Leveling system type	Type1/No present
Rear wiper mode	With Lo control
10MY SPEC	Enable
Rear wiper by reverse customize	Enabled(d.FR/RR)
ABS	Not present
A.S.C.	Present
Auto fold mirror	SPD/Not present
SAS	Present
4WD/AWC	Not present
TCM	Not present <M/T>
	Present <CVT, TC-SST>
ACTV_STB	Not used
Door unlock by IG lock customize	Enabled(def.D)
Rheostat cancel mode	Available
EPS	Not present
ACDAYC	Not present <4B12>
	Present <4B11>
Coming home light customize	Disabled or Enabled(def.E)
Welcome light customize	Disabled or Enable(d.Small)
Indirect light	Not present
Power window Dr	Present
Power window As	Not present
Power window RR	Not present
Power window RL	Not present
ESS by stoplight	Not present
Sunroof	Not present or Present
RLS	Not present or Present
Washer function improvement	Enable
IG key illumination	W/ getting off
Turn signal bulb	21W+21W+5W
Rear wiper	Enable
Fold mirror	Disabled
Headlight	4 beams
Comfort Hazard	Disabled
Head light washer	Disabled
Front fog light mode	A spec.

TSB Revision

Item name	Initial value
Front fog light*2	Present
Rear fog light*2	Not present/Chg OK
Room light delay timer/door and H/L	Long
Room light by H/L	Full
Gate/Trunk light	Mode-2 (cargo)
Headlight auto cut mode	C-spec
Headlight auto cut	Enable
Door lock system	A-spec (NAS)
Auto door lock/unlock	Disabled
key reminder unlock	B-spec/Dr and As
Horn type*2	Dual horn
Gate/trunk opener mode	Present (Type 1)
Cooling fan	Relay control
Security alarm mode	C-spec
Security alarm function	Present/Chg Ng
Pre-alarm	Not present
Multi mode RKE	Disabled
Gate/Trunk	Gate type
Manner switch	Not present/Chg Ng
Remote engine starter	Present/Chg OK
Panic Alarm	Enable
Room light improvement	Enable
Front wiper	Speed Sensitive or Rain Sensitive
Comfort flasher type	Present/Chg OK
Dome light Center Switch	Not present
Wiper washer check bulb*2	Present
AUDIO/S.RADIO type	Other
H/L leveling type	Not present
AFS/ACL*1 type	Not present
ESS by turn light	Not present
Compressor type*2	Scroll 90cc
Temperature type	Celsius or Fahrenheit
Rear view camera	Not present
Nose view camera	Not present
Side view camera	Not present

**GENERAL
PRECAUTIONS BEFORE SERVICE**

00-35

Item name	Initial value
Average speed	Available
Vehicle language status	English
Fuel amount	Not used
Fuel consumption scale	L/100km or MPG (US)
Speed gauge tolerance	U.S.
Coolant temp gauge threshold	Normal
Frost warning threshold	U.S.
Distance to empty	Available
Average fuel consumption	Available
Instant fuel consumption	Available
Time traveled	Not available
Distance traveled	Not available
Fuel used	Not available
Trip autoreset IG OFF	Available
Variable Speed Alarm	Not available
Rest reminder	Available
Instant speed	Not available
Seat belt reminder control type	AABT
Seat belt reminder flashing	Available
Seat belt reminder indicator	D & P independ
Reverse alarm	Not available
Key reminder	Available
Lighting monitor	Available
GCC speed alarm	Not available
Condition buzzer	Not available
Rent-a-car mode IG-OFF always	Available
Rent-a-car mode IG-OFF door open	Available
Service reminder schedule table	NAS 10 <4B12>
	NAS 20 <4B11>
ACD control display	Not used
TPMS information	32 psi <4B12>
	35 psi <4B11>
Horn chirp by keyless	Present/Chg OK
Rear S/R unlock output	Not present
Trailer turn detection	present

Item name	Initial value
Shift Lever	Not present <4B12>
	present <4B11>
AFS/ACL/Leveling	Not present
Satellite Radio ^{*2}	Not present or Present
Display opening type	MMC
F.A.S.T. auto lock customize	Not used
DRL function ^{*2}	Present/Chg Ng
FACU	Not present
S-AWC control display	Not available
Diesel particulate filter	Not present
Language mode	Available
WSS	Not present
Door Unlock Mode Customize ^{*2}	Disabled
RLS overwipe type	Type 1
RLS WS type	Type 2 (Green)
Interior illumination customize	Disabled

NOTE:

- ^{*1}: TPMS is an abbreviation of Tire Pressure Monitoring System, DRL of Daytime Running Light and AFS of Adaptive Front lighting System. However, the systems are not used for this vehicle.

- ^{*2}: The setting can be changed by the option coding. Refer to .

OPTION CODING**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: Vehicles Communication Interface (V.C.I.)
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A (Vehicles with CAN communication system)

⚠ CAUTION

- If there is any item indicated by the option coding after equipment change, set ETACS-ECU so that the option coding data corresponds with the equipment content. Functions and systems do not work normally if the setting does not correspond with the equipment.
- With the ETACS functions being customized, if any of the ETACS-ECU variant coding and option coding items are changed, the customized contents are reset. In such case, the functions need to be recustomized.

The ETACS-ECU option coding data can be checked or changed by operating scan tool MB991958.

- How to check option coding data
 1. Connect the scan tool MB991958. Refer to [P.00-28](#).
 2. Turn the ignition switch to the "ON" position.
 3. Select "System select" from the start-up screen.
 4. Select "From 2006 MY" under "Model Year". Check that "Vehicle Information" contents are correct.
 5. Select "ETACS" from "System List", and then press "OK" button.

NOTE: If "Loading Option Setup" list is shown, click appropriate box.

6. Select "Coding."
 7. Select "Option Coding Information."
 8. Check the displayed option coding information.
- How to change option coding data
 1. Connect the scan tool MB991958. Refer to [P.00-28](#).
 2. Turn the ignition switch to the "ON" position.
 3. Select "System select" from the start-up screen.
 4. Select "From 2006 MY" under "Model Year". Check that "Vehicle Information" contents are correct.
 5. Select "ETACS" from "System List", and then press "OK" button.

NOTE: If "Loading Option Setup" list is shown, click appropriate box.

6. Select "Coding."
7. Select "Option Coding."
8. Change to correct option coding data.

LIST

Item name
Number of speaker
Seat material
AUDIO (CAN)
AND
HFM (hands free-ECU)
Front fog light
Rear fog light
Horn type
Wiper washer check bulb
Compressor type
Satellite Radio
DRL function
Keyless
Door Unlock Mode Customize

INITIALIZATION PROCEDURE FOR LEARNING VALUE IN MFI ENGINE

M1001011701261

When the following service is performed, initialize the learning value.

- At replacing engine assembly*
- At replacing throttle body and at cleaning
- At replacing knock sensor

*NOTE: * Initialize CVT-related learning value.*


INITIALIZATION PROCEDURE**Required Special Tool:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: USB Cable
 - MB991910: Main Harness A

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

1. After the ignition switch is in "LOCK" (OFF) position, connect scan tool MB991958 to the data link connector.
2. Turn the ignition switch to the "ON" position.
3. Select "MFI" form System select Screen of scan tool MB991958.
4. Select "Special Function" form MFI Screen.
5. Select "Learned value reset" from Special Function Screen.
6. Select "All learned value" form Learned value reset Screen.
7. Initialize the learning value by pressing the "ON" button.
8. After initializing the learning value, the learning value of MFI engine idling is necessary. (Refer to, Engine Idling Learning Procedure [P.00-38](#)).

**ENGINE IDLING LEARNING PROCEDURE**

M1001011801235

PURPOSE

When the ECM is replaced, or when the learned value is initialized, the idle may not be stabilized. Carry out the learning method by following the procedures below.

LEARNING PROCEDURE

1. Start the engine and warm to reach 80° C (176° F) or more.

NOTE: When the engine coolant temperature is 80° C (176° F) or more, the warm-up is not needed if the ignition switch is in "ON" position once.

2. Turn the ignition switch to "LOCK" (OFF) position.
3. After 10 seconds or more, start the engine again.
4. For 10 minutes, carry out the idling under the condition shown below and then confirm the engine idles normally.
 - Transaxle: Neutral (P range on vehicles with CVT or TC-SST)
 - Operation in ignition-related, fan and attachments: Not to be operated
 - Engine coolant temperature: 80° C (176° F) or more

NOTE: If the engine stalls while idling, check for a dirty (on the throttle valve) of the throttle body and clean if needed. Then perform the service from Procedure 1 again.


INITIALIZATION PROCEDURE FOR THROTTLE ACTUATOR CONTROL MOTOR

When the battery cable is disconnected and reconnected, throttle actuator control motor valve (Fully closed position) is eliminated, so that the throttle valve opening angle control would not be performed correctly. When the battery cable is disconnected and reconnected, initialize the throttle actuator control motor using the following procedure.

1. Turn the ignition switch to the "ON" position then, turn the ignition switch to "LOCK" (OFF) position.
2. For 10 seconds or more, keep the ignition switch in "LOCK" (OFF) position.

TIMING CHAIN MAINTENANCE <2.0 L ENGINE>

M1001016500203



If the vehicle equipped with 2.0 L ENGINE Turbo continues the rough driving like competitive running*¹, the amount of carbon mixed into the engine oil tends to increase. This can possibly cause the timing chain to gradually elongate. To prevent this, the function or logic monitoring the amount of elongation of the timing chain is integrated into the ECM. When the ECM detects the elongation of the timing chain, the warning is shown on the multi-information display of combination meter as shown in the illustration. This gives the driver the information that the visual check of the elongation of the timing chain is necessary. If this warning is continuously neglected, the timing chain can possibly interfere with the other engine components, resulting in the engine damaged.

*NOTE: *1: The competitive running means the running that constantly repeats the cycle of the full opened position of the accelerator pedal and the full closed position of the accelerator pedal.*

The ECM stores the timing chain conditions as the initial learning value when the timing chain is installed. The ECM stores the amount of elongation of the timing chain in the EEPROM as the current learning value, compared with the initial learning value. The ECM judges that the visual check of the elongation of the timing chain is necessary when the current learning value exceeds the specified value. Thus, use the scan tool MB991958 to always carry out the maintenance of the initial learning value related to the timing chain that is stored by the ECM after the following service.

Service	Maintenance items by scan tool MB991958	Maintenance purpose
ECM replacement	<ul style="list-style-type: none"> • Learned value Read&Save *2 • Write learned value (Changed ECU)*2 	The purpose is that the initial learning value regarding the amount of elongation of the timing chain stored by the current ECM is loaded in the scan tool MB991958, and then written into the new ECM. This allows the ECM to appropriately monitor the amount of elongation of the timing chain after the ECM replacement.
Visual check of elongation of timing chain	Learned value reset	The purpose is that the initial learning value stored by the current ECM is initialized after the visual check of the elongation of the timing chain by illuminating the warning lamp, whether or not the timing chain is replaced. This allows the ECM to appropriately monitor the amount of elongation of the timing chain.
Timing chain or engine assembly replaced	Learned value reset	The purpose of this procedure is that the initial learning value stored by the current ECM is initialized when the timing chain or the engine assembly (the timing chain is also replaced with a new one.) is replaced. This allows the ECM to appropriately monitor the amount of elongation of the timing chain.

NOTE: *2: The visual check of the elongation of the timing chain must be carried out under the following conditions: when the initial learning value cannot be written into scan tool MB991958 from the current ECM because of the ECM malfunction and when the initial learning value cannot be written into the new ECM (Refer to GROUP 11A, On-vehicle Service –Timing Chain Elongation Visual Check P.11A-18). If elongated more than the specified length at this time, the timing chain can possibly interfere with the other engine components before the new ECM detects the elongation of the timing chain. The timing chain must be replaced with a new one to prevent engine damage.

LEARNED VALUE READ&SAVE AND WRITE LEARNED VALUE (CHANGED ECU)

Required Special Tool:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: USB Cable
 - MB991910: Main Harness A

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

1. After the ignition switch is in "LOCK" (OFF) position, connect scan tool MB991958 to the data link connector.
2. Turn the ignition switch to the "ON" position.
3. Select "MFI" from System select Screen of scan tool MB991958.
4. Select "Special Function" from MFI Screen.
5. Select "Timing chain maintenance" from Special Function Screen.
6. Select "Learned value Read&Save" from Timing chain maintenance Screen.
7. Press "OK" to store the initial learning value file.


NOTE: When the learning value file is appropriately stored, "Learned value Save Complete" is shown on the screen of the scan tool MB991958.

NOTE: Calculating the amount of elongation of the timing chain by the ECM takes the time. Thus, the file cannot be stored for a while after the ECM initialization or replacement.

8. Replace the ECM.
9. Select "Write learned value (Changed ECU)" from Timing chain maintenance Screen.
10. Select the initial learning value file stored during Step 7 to write the initial learning value.

NOTE: Use only the initial learning value file stored during Step 7 without using any other files.

NOTE: When the initial learning value is appropriately written, "Learned value writing Completed." is shown on the screen of the scan tool MB991958.




LEARNED VALUE RESET**Required Special Tool:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: USB Cable
 - MB991910: Main Harness A

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

1. After the ignition switch is in "LOCK" (OFF) position, connect scan tool MB991958 to the data link connector.
2. Turn the ignition switch to the "ON" position.
3. Select "MFI" from System select Screen of scan tool MB991958.
4. Select "Special Function" from MFI Screen.
5. Select "Timing chain maintenance" from Special Function Screen.
6. Select "Learned value reset" from Timing chain maintenance Screen.
7. Press "OK" to reset the initial learning value.

**TEST/LIMIT VALUE READOUT****Required Special Tool:**


- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: USB Cable
 - MB991910: Main Harness A

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

1. After the ignition switch is in "LOCK" (OFF) position, connect scan tool MB991958 to the data link connector.
2. Turn the ignition switch to the "ON" position.
3. Select "MFI" from System select Screen of scan tool MB991958.
4. Select "Special Function" from MFI Screen.
5. Select "Timing chain maintenance" from Special Function Screen.
6. Select "Test/Limit value readout" from Timing chain maintenance Screen.
7. Read the value of percentage (%) shown on the screen.

NOTE: The value of percentage (%) shown on the screen is the amount of elongation of the timing chain calculated by the ECM based on the initial learning value, and thus is not the actual amount. Use this for the reference only.



SERVICING ELECTRICAL SYSTEM


M1001011900433

⚠ WARNING

Battery posts, terminals and related accessories contain lead and lead compounds. WASH HANDS AFTER HANDLING.

1. Note the following before proceeding with working on the electrical system.

Never perform unauthorized modifications to any electrical device or wiring. Such modifications might lead to a vehicle malfunction, over-capacity or short-circuit that could result in a fire in the vehicle.



⚠ CAUTION

- Before connecting or disconnecting the negative battery cable, be sure to turn the ignition switch to the "LOCK" (OFF) position and turn off the lights (If this is not done, there is the possibility of semiconductor parts being damaged).
 - After completion of the work (and the negative battery terminals is connected), warm up the engine and allow it to idle for approximately 10 minutes under the conditions described below in order to stabilize engine control conditions, and then check to be sure that the idle is satisfactory.
 - Engine coolant temperature: 85 –95° C (185 –203° F)
 - Lights and all accessories: OFF
 - Transaxle: "P" position
 - Steering wheel: straight-forward position
2. When servicing the electrical system, disconnect the negative cable terminal from the battery.



HOW TO SHIFT LOCK FORCED RELEASE

M1001018100234

If the shift lever cannot be moved from the P position due to discharged battery or similar reasons, release the shift lock by observing the procedure below.


<TC-SST>

1. Remove the floor console box cup holder and the floor console panel assembly (Refer to GROUP 52A –Floor Console Assembly P.52A-9).
2. Turn the ignition switch to the position other than the LOCK (OFF) position.
3. Insert a screwdriver or a similar tool from the section "A" shown in the figure. While pressing the shift lock forced release switch, move the shift lever.



<CVT>


1. Turn the ignition switch to the position other than the LOCK (OFF) position.
2. Remove the shift lock forced release switch cover shown in the figure. While pressing the shift lock forced release switch with a screwdriver or a similar tool, move the selector lever.



VEHICLE WASHING

M1001012000682

1. If high-pressure car-washing equipment or steam car-washing equipment is used to wash the vehicle, be sure to maintain the spray nozzle at a distance of at least approximately 40cm (16 in.) from any plastic parts and all opening parts (doors, luggage compartment, etc.).
2. If high-pressure car-washing equipment or steam car-washing equipment is used to wash the vehicle, be sure to observe the following instructions to prevent damages to the plastic parts.
 - Spray nozzle distance: Approximately 40 cm (16 in.) or more
 - Spray pressure: 3,900 kPa or less
 - Spray temperature: 82 °C (180° F) or less
 - Time of intensive spraying to one point: Within 30 seconds



APPLICATION OF ANTI-CORROSION AGENTS AND UNDERCOATS

M1001011000117

Be careful not to apply oil or grease to the heated oxygen sensor. If applied, the sensor may malfunction. Protect the heated oxygen sensor with a cover before applying anti-corrosion agent, etc.

BOLTS AND NUTS WITH STABILIZER FOR COEFFICIENT OF FRICTION

M1001014800082

The bolts and nuts with stabilizer for coefficient of friction have been used for the connections such as the suspension arm and crossmember in order to stabilize the axial force and to ensure the high axial force at bolt/nut connections, resulting in improved reliability.

NOTE: The bolts and nuts with stabilizer for coefficient of friction mean that the bolts and nuts with surface treatment to stabilize and reduce the coefficient of friction, allowing to achieve the stable axial force and to secure the high axial force with low tightening torque.

FORM-IN-PLACE GASKET (FIPG)

M1001014200109

The engine has several parts to which the form-in-place gasket (FIPG) is used. To sufficiently achieve the aims of this gasket, it is necessary to pay attention to the application amount, procedure, and surface status.

If the application amount is too small, a leakage will occur. If the application amount is excessive, the FIPG will overflow and cause a clogging or narrowing of water and oil paths. Therefore, to eliminate the leak from the joint, it is indispensable that the FIPG be applied with a correct amount and without any gap.

Because the FIPG used for the engine parts becomes hardened by the reaction with the atmospheric moisture, it is normally used for the metal flange section.

CAUTION

Reapply the FIPG with care to the followings.

1. **Completely remove the old FIPG including the residue in gaps of parts.**
2. **Using Mitsubishi genuine parts cleaner (MZ100387) or equivalent, degrease the FIPG application surface carefully.**
3. **According to the FIPG application procedures, apply it accurately.**

DISASSEMBLY

The parts installed with the FIPG can be disassembled easily without using any special method. However, in some cases, it is necessary to tear the sealant in between the mating surfaces by tapping the parts with a wooden hammer or similar tools. It is

acceptable to lightly hit in a smooth, thin gasket scraper into the mating surface, but, in this case, a sufficient caution is required not to damage the mating surface. The oil pan FIPG cutter (Special tool: MD998727) is provided. Thus, use this special tool.

GASKET SURFACE CLEANING

Use a gasket scraper or wire brush to completely remove all the foreign materials adhering to the gasket surface. Check that the FIPG application surface is smooth. There must be no grease or foreign material adhesion to the gasket surface. Do not forget to remove the old FIPG remaining in the mounting hole and tapped hole.

APPLICATION PROCEDURE

Apply the FIPG with a specified diameter and without any gap. Completely enclose around the mounting hole. When the FIPG is not hardened, it can be wiped off. When the FIPG is still moistened (within three minutes), perform the installation to the specified position. At the time of installation, prevent the FIPG from adhering to locations other than it is necessary. After the installation, until a sufficient period of time (approximately for two hours) elapses, do not contact the oil or water to the application area. Also, do not start the engine. Because the FIPG application procedure may differ depending on the application area, apply the FIPG according to the procedure described in the text.

TOWING AND HOISTING


M1001000800926

WRECKER TOWING RECOMMENDATION

FRONT TOWING PICKUP <FWD>

⚠ CAUTION


- This vehicle cannot be towed by a wrecker using sling-type equipment; otherwise the bumper may become deformed. If this vehicle is towed, use wheel lift or flat bed equipment.
- The vehicle may be towed on its rear wheels for extended distances provided the parking brake is released. It is recommended that vehicles be towed using the front pickup whenever possible.



FRONT TOWING PICKUP <AWD>

⚠ CAUTION


- This vehicle cannot be towed by a wrecker using sling-type equipment; otherwise the bumper may become deformed. If this vehicle is towed, use wheel lift or flat bed equipment.
- The vehicle must not be towed by placing only its front wheels or only the rear wheels on a rolling dolly. This will result in deterioration of the viscous coupling causing the vehicle to jump forward suddenly.
- If this vehicle is towed, use flat bed equipment only.



REAR TOWING PICKUP

⚠ CAUTION

- This vehicle cannot be towed by a wrecker using sling-type equipment; as the bumper may become deformed. If this vehicle is towed, use wheel lift or flat bed equipment.
- The vehicle must not be towed by placing only its front wheels or only the rear wheels on a rolling dolly. This will result in deterioration of the viscous coupling causing the vehicle to jump forward suddenly. <AWD>
- Never lift the rear wheels, otherwise the vehicle becomes unstable while driving.
- If this vehicle is towed, use flat bed equipment only.



TOWING WHEN KEYS ARE NOT AVAILABLE

When a locked vehicle must be towed and keys are not available, the vehicle may be lifted and towed from the front, provided the parking brake is released. If not released, the rear wheels should be placed on a tow dolly.

SAFETY PRECAUTIONS

The following precautions should be taken when towing the vehicle:

1. Do not lift or tow the vehicle by attaching to or wrapping around the bumper.
2. Any loose, protruding, or damaged parts such as hoods, doors, fenders, trim, etc. should be secured or removed prior to moving the vehicle.
3. Refrain from going under a vehicle when it is lifted by the towing equipment, unless the vehicle is adequately supported by safety stands.
4. Never allow passengers to ride in a towed vehicle.
5. State and local rules and regulations must be followed when towing a vehicle.




LIFTING, JACKING SUPPORT LOCATION

FLOOR JACK



⚠ CAUTION

- Never place a support at any point other than the specified one, or that point will be deformed.
- For lifting, put rubber or similar material between the side sill and rigid rack, otherwise the side sill area will be damaged.

FLOOR JACK



RIGID RACK




POST TYPE

Special care should be taken when raising the vehicle on a frame contact type hoist. The hoist must be equipped with the proper adapters in order to support the vehicle at the proper locations.

⚠ CAUTION

When service procedures require removing rear suspension, fuel tank and spare tire, place additional weight on the rear end of vehicle, or anchor vehicle to hoist to prevent tipping when the location of the center of gravity changes.



AC802555AB

TIGHTENING TORQUE

M1001001100964

Each torque value in the table is a standard value for tightening under the following conditions.

1. Bolts, nuts and washers are all made of steel and plated with zinc.
2. The threads and bearing surface of bolts and nuts are all in dry condition.

The values in the table are not applicable:

1. If toothed washers are inserted.
2. If plastic parts are fastened.
3. If bolts are tightened to plastic or die-cast inserted nuts.
4. If self-tapping screws or self-locking nuts are used.

STANDARD BOLT AND NUT TIGHTENING TORQUE

Thread size		Standard tightening torque		
Nominal bolt diameter (mm)	Pitch (mm)	Head mark "4"	Head mark "7"	Head mark "8"
M5	0.8	2.5 ± 0.5 N· m (23 ± 4 in-lb)	5.0 ± 1.0 N· m (44 ± 9 in-lb)	6.0 ± 1.0 N· m (53 ± 9 in-lb)
M6	1.0	5.0 ± 1.0 N· m (44 ± 9 in-lb)	8.5 ± 1.5 N· m (76 ± 13 in-lb)	10 ± 2 N· m (89 ± 17 in-lb)
M8	1.25	11 ± 2 N· m (98 ± 17 in-lb)	20 ± 4 N· m (15 ± 3 ft-lb)	24 ± 4 N· m (18 ± 3 ft-lb)
M10	1.25	23 ± 4 N· m (17 ± 3 ft-lb)	42 ± 8 N· m (31 ± 6 ft-lb)	53 ± 7 N· m (39 ± 5 ft-lb)
M12	1.25	42 ± 8 N· m (31 ± 6 ft-lb)	80 ± 10 N· m (59 ± 7 ft-lb)	93 ± 12 N· m (68 ± 9 ft-lb)
M14	1.5	70 ± 10 N· m (52 ± 7 ft-lb)	130 ± 20 N· m (96 ± 15 ft-lb)	150 ± 20 N· m (111 ± 14 ft-lb)
M16	1.5	105 ± 15 N· m (78 ± 11 ft-lb)	195 ± 25 N· m (144 ± 18 ft-lb)	230 ± 30 N· m (170 ± 22 ft-lb)
M18	1.5	150 ± 20 N· m (111 ± 14 ft-lb)	290 ± 40 N· m (214 ± 29 ft-lb)	335 ± 45 N· m (247 ± 33 ft-lb)
M20	1.5	210 ± 30 N· m (155 ± 22 ft-lb)	400 ± 60 N· m (295 ± 44 ft-lb)	465 ± 65 N· m (343 ± 48 ft-lb)
M22	1.5	290 ± 40 N· m (214 ± 29 ft-lb)	540 ± 80 N· m (398 ± 59 ft-lb)	630 ± 90 N· m (465 ± 66 ft-lb)
M24	1.5	375 ± 55 N· m (277 ± 40 ft-lb)	705 ± 105 N· m (520 ± 77 ft-lb)	820 ± 120 N· m (605 ± 88 ft-lb)

FLANGE BOLT AND NUT TIGHTENING TORQUE

Thread size		Standard tightening torque		
Nominal bolt diameter (mm)	Pitch (mm)	Head mark "4"	Head mark "7"	Head mark "8"
M6	1.0	5.0 ± 1.0 N· m (44 ± 9 in-lb)	10 ± 2 N· m (89 ± 17 in-lb)	12 ± 2 N· m (107 ± 17 in-lb)
M8	1.25	13 ± 2 N· m (111 ± 22 in-lb)	24 ± 4 N· m (18 ± 3 ft-lb)	28 ± 5 N· m (20 ± 4 ft-lb)
M10	1.25	26 ± 5 N· m (19 ± 4 ft-lb)	50 ± 5 N· m (37 ± 4 ft-lb)	58 ± 7 N· m (43 ± 5 ft-lb)
M10	1.5	25 ± 4 N· m (18 ± 3 ft-lb)	46 ± 8 N· m (34 ± 6 ft-lb)	55 ± 5 N· m (41 ± 3 ft-lb)
M12	1.25	47 ± 9 N· m (35 ± 6 ft-lb)	93 ± 12 N· m (68 ± 9 ft-lb)	105 ± 15 N· m (78 ± 11 ft-lb)
M12	1.75	43 ± 8 N· m (32 ± 6 ft-lb)	83 ± 12 N· m (61 ± 9 ft-lb)	98 ± 12 N· m (72 ± 9 ft-lb)

LUBRICATION AND MAINTENANCE

M1001001200488

Maintenance and lubrication service recommendations have been compiled to provide maximum protection for the vehicle owner's investment against all reasonable types of driving conditions. Since these conditions vary with the individual vehicle owner's driving habits, the area in which the vehicle is operated and the type of driving to which the vehicle is subjected, it is necessary to prescribe lubrication and maintenance service on a time frequency as well as mileage interval basis.

Oils, lubricants and greases are classified and graded according to standards recommended by the Society of Automotive Engineers (SAE), the American Petroleum Institute (API) and the National Lubricating Grease Institute (NLGI).

MAINTENANCE SCHEDULES

Information for service maintenance is provided in the "SCHEDULED MAINTENANCE TABLE." Three schedules are provided; one for "Required Maintenance," one for "General Maintenance" and one for "Severe Usage Service."

The item numbers in "SCHEDULED MAINTENANCE TABLE" correspond to the section numbers in "MAINTENANCE SERVICE."

SEVERE SERVICE

Vehicles operating under severe service conditions will require more frequent service.

Component service information is included for vehicles operating under one or more of the following conditions:

1. Trailer towing or police, taxi or commercial type operation.
2. Operation of Vehicle
 - (1) Short-trip operation at freezing temperature (engine not thoroughly warmed up)
 - (2) More than 50% operation in heavy city traffic during hot weather above 32° C (90° F)
 - (3) Extensive idling
 - (4) Driving in sandy areas
 - (5) Driving in salty areas
 - (6) Driving in dusty conditions
 - (7) Driving off-road

ENGINE OIL**⚠ CAUTION**

Test results submitted to EPA have shown that laboratory animals develop skin cancer after prolonged contact with used engine oil. Accordingly, the potential exists for humans to develop a number of skin disorders, including cancer, from such exposure to used engine oil. Therefore, when changing engine oil, be careful not to touch it as much as possible. Protective clothing and gloves, that cannot be penetrated by oil, should be worn. The skin should be thoroughly washed with soap and water, or use waterless hand cleaner, to remove any used engine oil. Do not use gasoline, thinners, or solvents.

Either of the following engine oils should be used: Engine oils displaying ILSAC certification symbol or conforming to the API classification SM. For further details, refer to "LUBRICANTS SELECTION."

LUBRICANTS AND GREASES

Semi-solid lubricants bear the NLGI designation and are further classified as grades 0, 1, 2, 3, etc. Whenever "Chassis Lubricant" is specified, Multipurpose Grease, NLGI grade Number 2, should be used.

FUEL USAGE STATEMENT

CAUTION

Using leaded gasoline in this car will damage the catalytic converters and heated oxygen sensors, and affect the warranty coverage validity.

This vehicle must use unleaded gasoline only.

This vehicle has a fuel filler tube which is especially designed to accept only the smaller-diameter unleaded gasoline dispensing nozzle.

GASOLINE CONTAINING ALCOHOL

Some gasoline sold at service stations contain alcohol although they may not be so identified.

Using fuels containing alcohol is not recommended unless the nature of the blend can be determined as being satisfactory.

Gasohol: A mixture of 10% ethanol (grain alcohol) and 90% unleaded gasoline may be used in your vehicle. If driveability problems are experienced as a result of using gasohol, it is recommended that the vehicle be operated on gasoline.

Methanol: **Do not use gasoline containing methanol (wood alcohol).** Using this type of alcohol can result in vehicle performance deterioration and damage critical parts in the fuel system components. Fuel system damage and performance problems resulting from the use of gasoline containing methanol may not be covered by the new vehicle warranty.

GASOLINE CONTAINING METHYL TERTIARY BUTYL ETHER (MTBE)

Unleaded gasoline containing 15% or less MTBE may be used in your vehicle. (Fuel containing MTBE over 15% in volume may cause reduced engine performance and produce vapor lock or hard starting.)

MATERIALS ADDED TO FUEL

Indiscriminate use of fuel system cleaning agents should be avoided. Many of these materials intended for gum and varnish removal may contain highly active solvents or similar ingredients that can be harmful to gasket and diaphragm materials used in fuel system component parts.

RECOMMENDED LUBRICANTS AND LUBRICANT CAPACITIES TABLE

M1001001300764

RECOMMENDED LUBRICANTS

Lubricant		Specification	Remark
Engine oil		Engine oils displaying ILSAC certification symbol ("Starburst" symbol) or conforming to the API classification SM or higher	For further details, refer to "LUBRICANTS SELECTION" section.
Transmission oil <M/T>		DiaQueen NEW MULTI GEAR OIL API classification GL-3, SAE 75W-80	-
Transmission fluid	<TC-SST>	Dia Queen SSTF-I	-
	<CVT>	DIA QUEEN CVTF-J1	-
Power steering fluid		Genuine MITSUBISHI power steering fluid or ATF DEXRON III or DEXRON II	-
Brakes and clutch		Conforming to Brake fluid DOT 3 or DOT 4	-
Engine coolant		Long life antifreeze coolant or an equivalent	-
Door hinges, back door hinges		Grease	-

LUBRICANT CAPACITY TABLE

Description		Specification	
Engine oil dm ³ (qt)	Oil pan (excluding oil filter)	2.0 L engine	5.1 (5.4)
		2.4 L engine	4.6 (4.8)
	Oil filter		0.3 (0.3)
Engine coolant dm ³ (qt)	2.0L ENGINE	7.5 (7.9)	
	2.4L ENGINE	7.0 (7.4)	
Transmission oil dm ³ (qt)	M/T	2.5 (2.6)	
	TC-SST	7.6 (8.0)	
Transmission fluid dm ³ (qt)	CVT	7.8 (8.2)	
Power steering fluid dm ³ (qt)		1.0 (1.06)	
Fuel tank dm ³ (gal)	2.0 L engine	55.0 (14.5)	
	2.4 L engine	59.0 (15.5)	



LUBRICANT SELECTION

ENGINE OIL

⚠ CAUTION

Never use nondetergent or straight mineral oil.

Use only engine oils displaying the ILSAC certification symbol ("Starburst" symbol) on the container.




If these oils are not available, an API classification SM or higher can be used.

OIL VISCOSITY <2.0L ENGINE>

⚠ CAUTION

For vehicles with turbocharger, engine oil must be properly maintained to avoid engine and/or turbocharger damage. To better protect your engine and turbocharger, use fully synthetic engine oil.


NOTE: SAE 0W-30 and 0W-40 engine oil are recommended to use to improve engine startability on a very cold weather condition.



OIL VISCOSITY < 2.4L ENGINE>

The SAE grade number indicates the viscosity of the oil. A proper SAE grade number should be selected according to ambient temperature.

NOTE: SAE 5W-20 engine oil is strongly recommended for optimum fuel economy and cold starting. SAE 10W-30 may be used when the normal operating temperature is above 38°C (100°F.)



SELECTION OF COOLANT

COOLANT

Relationship between Coolant Concentration and Specific Gravity

⚠ CAUTION

- If the concentration of the coolant is below 30%, the anti-corrosion property will be adversely affected. In addition, if the concentration is above 60%, both the anti-freeze and engine cooling properties will decrease, affecting the engine adversely. For these reasons, be sure to maintain the concentration level within the specified range.
- Do not use a mixture of different brands of anti-freeze.

Coolant temperature °C (°F) and specific gravity					Freezing temperature	safe operating temperature	Coolant concentration (Specific volume)
10 (50)	20 (68)	30 (86)	40 (104)	50 (122)	°C (°F)	°C (°F)	%
1.054	1.050	1.046	1.042	1.036	-16 (3.2)	-11 (12.2)	30
1.063	1.058	1.054	1.049	1.044	-20 (-4)	-15 (5)	35
1.071	1.067	1.062	1.057	1.052	-25 (-13)	-20 (-4)	40
1.079	1.074	1.069	1.064	1.058	-30 (-22)	-25 (-13)	45
1.087	1.082	1.076	1.070	1.064	-36 (-32.8)	-31 (-23.8)	50
1.095	1.090	1.084	1.077	1.070	-42 (-44)	-37 (-35)	55
1.103	1.098	1.092	1.084	1.076	-50 (-58)	-45 (-49)	60

Example

The safe operating temperature is -15° C (5° F) when the specific gravity is 1.058 at the coolant temperature of 20° C (68° F)

SCHEDULED MAINTENANCE TABLE

<2.0L ENGINE>

M1001001401021

SCHEDULED MAINTENANCE SERVICE FOR EMISSION CONTROL AND PROPER VEHICLE PERFORMANCE

Inspection and service should be performed any time a malfunction is observed or suspected.

No.	Emission control system maintenance	Service intervals	Mileage in thousands	15	30	45	60	75	90	105	120	135	150
			Kilometers in thousands	24	48	72	96	120	144	168	192	216	240
			Months	15	30	45	60	75	90	105	120	135	150
1	Fuel system (tank, pipe line and connection, and fuel tank filler tube cap)	Check for leaks			X*		X		X		X		X
2	Fuel hoses	Check condition			X*		X		X		X		X
3	Air cleaner element	Replace	X*	X	X	X	X	X	X	X	X	X	X
4	Evaporative emission control system (except evaporative emission canister)	Check for leaks and clogging				X					X		
5	Spark plugs	Iridium-tipped type	Replace				X				X		
6	Intake and exhaust valve clearance	Inspect and adjust				X					X		
			If valve noise increases, adjust valve clearance										
7	Drive belts (for the generator and power steering oil pump)	Replace		X		X		X		X		X	
8	Exhaust system (connection portion of muffler, muffler pipes and converter heat shields)	Check and service		X*		X		X		X		X	

NOTE: *: This maintenance is recommended but is not required to maintain the emissions warranty.

GENERAL MAINTENANCE SERVICE FOR PROPER VEHICLE PERFORMANCE

No.	General maintenance	Service intervals	Mileage in thousands	15	30	45	60	75	90	105	120	135	150	
				Kilometers in thousands	24	48	72	96	120	144	168	192	216	240
				Months	15	30	45	60	75	90	105	120	135	150
9	Engine oil	Turbocharger	Change	Every 5,000 miles (8,000 km) or every 5 months										
10	Engine oil filter	Turbocharger	Replace	Every 10,000 miles (16,000 km) or every 10 months										
11	Twin clutch sportronic shift transmission fluid	Check fluid leaks		X	X	X	X	X	X	X	X	X	X	
		Change					X				X			
12	Twin clutch sportronic shift transmission oil filter	Change					X				X			
13	Transfer oil (with ACD* ¹)	Check oil level		X	X	X	X	X	X	X	X	X	X	
		Change			X		X		X		X		X	
14	Reserve tank (for ACD* ¹)	Check fluid level		X	X	X	X	X	X	X	X	X	X	
15	Engine coolant	Change			X		X		X		X		X	
16	Coolant hoses (radiator hose, heater hose)	Inspect			X		X		X		X		X	
		Replace					X				X			
17	Disk brake pads, rotors	Inspect for wear		Every 5,000 miles (8,000 km) or every 5 months										
18	Brake hoses	Check for deterioration or leaks		X	X	X	X	X	X	X	X	X	X	
19	Ball joint and steering linkage seals	Inspect for grease leaks and damage		X	X	X	X	X	X	X	X	X	X	
20	Driveshaft boots	Inspect for grease leaks and damage		Every 5,000 miles (8,000 km) or every 5 months										
21	Suspension system	Inspect for looseness and damage		Every 5,000 miles (8,000 km) or every 5 months										
22	Rear axle oil (with LSD)	Change			X		X		X		X		X	
23	Tires	Rotate		Every 5,000 miles (8,000 km) or every 5 months										
24	Air purifier filter	Replace		X	X	X	X	X	X	X	X	X	X	

NOTE: *¹: ACD (Active Center Differential)

SCHEDULED MAINTENANCE UNDER SEVERE USAGE CONDITIONS

Maintenance should be carried out according to the following table:

No.	Maintenance item	Service intervals	Mileage in thousands	15	30	45	60	75	90	105	120	135	150
			Kilometers in thousands	24	48	72	96	120	144	168	192	216	240
			Months	15	30	45	60	75	90	105	120	135	150
9	Engine oil	Turbo	Change	Every 3,000 miles (4,800 km) or every 3 months									
10	Engine oil filter	Turbo	Replace	Every 6,000 miles (9,600 km) or every 6 months									
11	Twin clutch sportronic shift transmission fluid	Change		X		X		X		X		X	
12	Twin clutch sportronic shift transmission oil filter	Change		X		X		X		X		X	
13	Transfer oil	Change	X	X	X	X	X	X	X	X	X	X	X
17	Disk brake pads, rotors	Inspect for wear	Every 3,000 miles (4,800 km) or every 3 months										
20	Drive shaft boots	Inspect for grease leaks and damage	Every 3,000 miles (4,800 km) or every 3 months										
21	Suspension system	Inspect for looseness and damage	Every 3,000 miles (4,800 km) or every 3 months										
23	Tires	Rotate	Every 3,000 miles (4,800 km) or every 3 months										
24	Air purifier filter	Inspect for clogging	Every 3,000 miles (4,800 km) or every 3 months										
		Replace	Every 6,000 miles (9,600 km) or every 6 months										

NOTE: *1: ACD (Active Center Differential)

Severe usage conditions:

- Driving on dusty, rough, muddy or salt-spread roads
- Towing or police, taxi or commercial operation
- Extensive idling and/or low speed operation
- Repeated short-trip operation at freezing temperatures (engine not thoroughly warmed up)
- Extended use of brakes while driving
- Driving in sandy areas
- More than 50% operation in heavy city traffic during hot weather above 32° C (90° F)

<2.4L ENGINE>

M1001001401032

SCHEDULED MAINTENANCE SERVICE FOR EMISSION CONTROL AND PROPER VEHICLE PERFORMANCE

Inspection and service should be performed any time if a malfunction is observed or suspected.

No.	Emission control system maintenance	Service intervals	Mileage in thousands	15	30	45	60	75	90	105	120	135	150
			Kilometers in thousands	24	48	72	96	120	144	168	192	216	240
			Months	12	24	36	48	60	72	84	96	108	120
1	Fuel system (tank, pipe line and connection, and fuel tank filler tube cap)	Check for leaks					X				X		
2	Fuel hoses	Check condition		X ^{*1}			X		X		X		X
3	Air cleaner element	Replace		X			X		X		X		X
4	Evaporative emission control system (except evaporative emission canister)	Check for leaks and clogging					X				X		
5	Spark plugs	Iridium-tipped type	Replace	Every 105,000 miles (168,000 km) or every 84 months									
6	Intake and exhaust valve clearance	Inspect and adjust					X				X		
7	Drive belt (for the generator and power steering oil pump)	Check condition		X			X		X		X		X
8	Exhaust system (connection portion of muffler, muffler pipes and converter heat shields)	Check and service		X ^{*1}			X		X		X		X

NOTE:

^{*1}: This maintenance is recommended but is not required to maintain the emissions warranty.

GENERAL MAINTENANCE SERVICE FOR PROPER VEHICLE PERFORMANCE

No.	General maintenance	Service intervals	Mileage in thousands	15	30	45	60	75	90	105	120	135	150
			Kilometers in thousands	24	48	72	96	120	144	168	192	216	240
			Months	12	24	36	48	60	72	84	96	108	120
9	Engine oil	Change	Every 7,500 miles (12,000 km) or every 6 months										
10	Engine oil filter	Replace	Every 7,500 miles (12,000 km) or every 6 months										
11	Transmission oil <M/T>	Check oil level and condition		X		X		X		X		X	
13	Engine coolant	Change				X at first		X		X		X	
14	Coolant hoses (radiator hose, heater hose)	Inspect		X		X		X		X		X	
15	Disk brake pads, rotors	Inspect for wear	X	X	X	X	X	X	X	X	X	X	X
16	Brake hoses	Check for deterioration or leaks	X	X	X	X	X	X	X	X	X	X	X
17	Ball joint and steering linkage seals	Inspect for grease leaks and damage		X		X		X		X		X	
18	Drive shaft boots	Inspect for grease leaks and damage	X	X	X	X	X	X	X	X	X	X	X
19	Suspension system	Inspect for looseness and damage		X		X		X		X		X	
20	Tires	Rotate	Every 7,500 miles (12,000 km)										
21	Air purifier filter	Replace	X	X	X	X	X	X	X	X	X	X	X

SCHEDULED MAINTENANCE UNDER SEVERE USAGE CONDITIONS

Maintenance should be carried out according to the following table:

NO.	Maintenance item	Service intervals	Mileage in thousands	15	30	45	60	75	90	105	120	135	150
			Kilometers in thousands	24	48	72	96	120	144	168	192	216	240
			Months	12	24	36	48	60	72	84	96	108	120
3	Air cleaner element	Replace		X	X	X	X	X	X	X	X	X	X
9	Engine oil	Change	Every 3,750 miles (6,000 km) or every 3 months										
10	Engine oil filter	Replace	Every 3,750 miles (6,000 km) or every 3 months										
11	Transmission oil <M/T>	Change oil		X		X		X		X		X	
12	Transmission fluid <CVT>	Check oil level and condition	X	X	X	X	X	X	X	X	X	X	X
		Change fluid		X		X		X		X		X	
15	Disk brake pads, rotors	Inspect for wear	Every 7,500 miles (12,000 km) or every 6 months										
19	Suspension system	Inspect for looseness and damage	Every 7,500 miles (12,000 km) or every 6 months										
20	Tires	Rotate	Every 3,750 miles (6,000 km)										
21	Air purifier filter	Inspect for clogging	Every 3,750 miles (6,000 km) or every 3 months										
		Replace	Every 7,500 miles (12,000 km) or every 6 months										

Severe usage conditions:

1. Driving on dusty, rough, muddy or salt-spread roads
2. Towing or police, taxi or commercial operation
3. Extensive idling and/or low speed operation
4. Repeated short-trip operation at freezing temperatures (engine not thoroughly warmed up)
5. Extended use of brakes while driving
6. Driving in sandy areas
7. More than 50% operation in heavy city traffic during hot weather above 32° C (90° F)

MAINTENANCE SERVICE <2.0L ENGINE>

1. FUEL SYSTEM (TANK, PIPE LINE AND CONNECTION, AND FUEL TANK FILLER TUBE CAP) (CHECK FOR LEAKS)

M1001001600367

Check for damage or leakage in the fuel lines and connections.

2. FUEL HOSES (CHECK CONDITION)

M1001001700331

1. Inspect the surface of fuel hoses for heat and mechanical damage. Hard and brittle rubber, cracking, tears, cuts, abrasions and excessive swelling indicate deterioration of the rubber.
2. If the fabric casing of the rubber hose is exposed by cracks and abrasions in the fuel system, the hoses should be replaced.


3. AIR CLEANER ELEMENT (REPLACE)

M1001001800457

The air cleaner element will become dirty during use, reducing its effectiveness. Replace it with a new one.

Replacement of air cleaner element

1. Unclamp the air cleaner housing.
2. Remove the air cleaner element and install a new one.
3. When clamping the air cleaner housing in place, be sure that the cover is completely closed.



4. EVAPORATIVE EMISSION CONTROL SYSTEM (EXCEPT EVAPORATIVE EMISSION CANISTER) (CHECK FOR LEAKS AND CLOGGING)

M1001001900410

If the fuel-vapor vent line is clogged or damaged, fuel vapor will escape into the atmosphere causing excessive emissions. Disconnect the line at both ends, and blow it clean with compressed air. Remove the fuel tank filler tube cap from the filler tube and check to see if there is evidence that the seal makes improper contact to the filler tube.

5. SPARK PLUGS (REPLACE)

M1001002000540

⚠ CAUTION

Iridium plugs are used. Use care not to damage the electrode of the plugs. Do not adjust the spark plug gap.

1. Spark plugs must spark properly to assure proper engine performance and reduce exhaust emission level.

Therefore, they should be replaced periodically with new ones.

Spark plug type

Maker	Identification No.
NGK	ILKR7E6

2. The new plugs should be checked for the proper gap.

Spark plug gap: 0.5 –0.6 mm (0.020 –0.023 inch)

3. Install the spark plugs and tighten to 18 ± 2 N·m (13 ± 1 ft-lb).

6. INTAKE AND EXHAUST VALVE CLEARANCE (INSPECT AND ADJUST)

M1001012900276



NOTE: Perform the valve clearance check and adjustment at the engine cold state.

1. Remove all of the ignition coils.
2. Remove the cylinder head cover.

⚠ CAUTION

Turn the crankshaft always clockwise.

3. Turn the crankshaft clockwise, and align the timing mark on the exhaust camshaft sprocket against the upper face of the cylinder head as shown in Figure. Therefore, No.1 cylinder goes to the compression top dead center.







4. Using a thickness gauge, measure the valve clearance with the arrow shown in Figure. If deviated from the standard value, make note for the valve clearance.

Standard value:

Intake valve 0.20 ± 0.03 mm (0.008 ± 0.001 inch)

Exhaust valve 0.30 ± 0.03 mm (0.012 ± 0.001 inch)



5. Turn the crankshaft clockwise 360 degrees, and put the timing mark on the exhaust camshaft sprocket in position shown in Figure. Therefore, No. 4 cylinder goes to the compression top dead center.
6. Check the valve clearance with the arrow shown in Figure. In the same procedure as 4.
7. If the valve clearance is deviated from the standard value, remove the camshaft and the valve tappet. For the camshaft removal (Refer to GROUP 11A, Camshaft –Removal and Installation P.11A-27).
8. Using a micrometer, measure the thickness of the removed valve tappet.
9. Calculate the thickness of the newly installed valve tappet through the following equation.
 - A: thickness of newly installed valve tappet
 - B: thickness of removed valve tappet
 - C: measured valve clearance

Equation
Intake valve: $A = B + [C - 0.20 \text{ mm (0.008 inch)}]$
Exhaust valve: $A = B + [C - 0.30 \text{ mm (0.012 inch)}]$

NOTE: The valve tappet ranges 3,000 –3,690 mm (0.1181 – 0.1453 inch) and has 47 types per 0.015 mm (0.0006 inch). The thickness below a decimal point is stamped on the reverse side of the valve tappet.
10. Install the valve tappet selected through the procedure 9, and put the camshaft in position. For the camshaft installation (Refer to GROUP 11A, Camshaft –Removal and Installation P.11A-27).
11. After installing the timing chain, measure the valve clearance using the procedure 3 to 6. Confirm the clearance is within the standard value.

⚠ CAUTION

Completely remove all the old FIPG, which might be remaining among the components.

12. After completely removing the liquid gasket adhering on the timing chain case, cylinder head and cylinder head cover, degrease them.



CAUTION

The cylinder head cover should be installed within 3 minutes of applying liquid gasket.

13. Apply a 4 mm (0.16 in) bead of liquid gasket as illustrated.

Specified sealant:

THREE BOND 1217G or equivalent



14. Install the cylinder head cover and tighten the tightening bolts using the following procedures.

(1) Temporarily tighten to the following torque in order shown in the illustration.

Tightening torque: $3.0 \pm 1.0 \text{ N} \cdot \text{m}$ ($27 \pm 8 \text{ in-lb}$)

(2) Tighten to the specified torque in order shown in the illustration.

Specified torque: $5.5 \pm 0.5 \text{ N} \cdot \text{m}$ ($49 \pm 4 \text{ in-lb}$)

15. Install the ignition coils.

7. DRIVE BELT (FOR THE GENERATOR AND POWER STEERING OIL PUMP) (REPLACE)

M1001002500675

1. Remove the radiator condenser tank. (Refer to GROUP 14, Radiator P.14-50.)

CAUTION


Check the drive belt tension after turning the crankshaft clockwise one turn or more.

2. Make sure that the indicator mark on the auto-tensioner is within the area marked with A in the illustration.

3. If the mark is out of the area A, replace the drive belt. (Refer to GROUP 11A-Crankshaft Pulley P.11A-22.)

NOTE: The drive belt tension check is not necessary as the auto-tensioner is adopted.

4. Install the radiator condenser tank. (Refer to GROUP 14, Radiator P.14-50.)



8. EXHAUST SYSTEM (CONNECTIONS PORTION OF MUFFLER, MUFFLER PIPES AND CONVERTER HEAT SHIELDS) (CHECK AND SERVICE)

M1001005800459

Check for holes and exhaust gas leaks due to damage, corrosion, etc.

1. Check the joints and connections for looseness and exhaust gas leaks.
2. Check the rubber hangers and brackets for damage.

9. ENGINE OIL (CHANGE)

M1001002600746



1. Start the engine and allow it to warm up until the temperature of the engine coolant reaches 80 –90° C (176 – 194° F.)

⚠ WARNING

Use care as engine oil could be hot.

2. Remove the engine oil filler cap.
3. Remove the engine room under cover extension (Refer to GROUP 51, Under Cover P.51-20.)
4. Remove the engine oil pan drain plug to drain engine oil.
5. Install a new engine oil pan drain plug gasket so that it faces in the direction shown in the illustration, and then tighten the engine oil pan drain plug to the specified torque.

Tightening torque: 39 ± 5 N· m (29 ± 3 ft-lb)



⚠ CAUTION

For vehicles with turbocharger, engine oil must be properly maintained to avoid engine and/or turbocharger damage. To better protect your engine and turbocharger, use fully synthetic engine oil.

6. Refill with specified quantity of engine oil.

Specified Engine Oil: Engine oils displaying ILSAC certification symbol ("Starburst" symbol) or conforming to the API classification SM or higher

Total quantity: 5.1 dm³ (5.4 quarts)

NOTE: SAE 0W-30 and 0W-40 engine oil are recommended to use to improve engine startability on a very cold weather condition.

7. Install the engine oil filler cap.
8. Let the engine run for a few minutes.
9. Stop the engine, and then check the engine oil level using the engine oil level gauge after a few minutes.
10. Install the engine room under cover extension (Refer to GROUP 51, Under Cover P.51-20.)

10. ENGINE OIL FILTER (REPLACE)

M1001002700635

1. Start the engine and allow it to warm up until the temperature of the engine coolant reaches 80 –90° C (176 – 194° F.)

⚠ WARNING***Use care as engine oil could be hot.***

2. Remove the engine oil filler cap.
3. Remove the engine room under cover extension (Refer to GROUP 51, Under Cover P.51-20.)
4. Remove the engine oil pan drain plug to drain engine oil.
5. Use the respective tool in the following table to remove the engine oil filter.

Number	Special tool
MD356000	MB991610 or equivalent

6. Clean the filter bracket side mounting surface and ensure the old O-ring has been removed.

7. Apply a small amount of engine oil to the O-ring of the new engine oil filter.
8. Screw on the engine oil filter by hand until it touches the surface of the flange and then tighten it with an oil filter wrench.

Number	Special tool	Tightening torque
MD356000	MB991610 or equivalent	Approximately 3/4 turn [14 ± 2 N· m (124 ± 17 in-lb)]



9. Install the engine oil pan drain plug and refill the engine oil (Refer to P.12-5.)
10. Rev the engine a few times, and check to be sure that no engine oil leaks from the installation section of the engine oil filter.
11. Install the engine room under cover extension (Refer to GROUP 51, Under Cover P.51-20.)

11. TWIN CLUTCH-SPORTRONIC SHIFT TRANSMISSION (TC-SST) [CHECK THE FLUID LEAKAGE (IF NECESSARY, CHECK THE FLUID LEVEL) /CHANGE]

M1001016600040



TC-SST FLUID LEAKAGE CHECK

1. Clean the TC-SST exterior, and visually check the TC-SST for fluid leaks.
2. If the fluid is leaking from the oil pan or the oil seal, replace the part. If the fluid is leaking from the part other than the oil pan and the oil seal, replace the TC-SST assembly.



TC-SST FLUID LEVEL CHECK

1. Remove the engine room under cover front B assembly. (Refer to GROUP 51 –Under Cover P.51-20.)
2. Start the engine, and let it run at idle to warm it up for 15 minutes.
3. Move the shift lever to every position (P, R, N, D, manual mode) (Hold for 20 seconds in each position), and then move it to the P range.
4. Stop the engine.
5. Remove the air cleaner element and air cleaner intake duct. (Refer to GROUP 15 –Air Cleaner P.15-9.)
6. Remove the filler plug.



⚠ CAUTION

- The drained fluid can be reused if it is between the replacement intervals.

<Replacement interval>

- Normal condition: 96,000 km (60,000 miles)
- Severe condition: 48,000 km (30,000 miles)
- When reusing the drained fluid, make sure that no foreign object gets into the fluid.

7. Remove the drain plugs, and leave it for 3 minutes to drain the fluid.
NOTE: Because the fluid in the oil cooler, oil filter, and TC-SST assembly cannot be drained, the amount of drained fluid will be approximately 5.5 dm³ (approximately 5.8 quarts).
8. Tighten the drain plugs to the specified torque.

Tightening torque: 35 ± 5 N· m (26 ± 4 ft-lb)



⚠ CAUTION

Measure the drained fluid. If the drained fluid is less than approximately 5.5 dm³ (approximately 5.8 quarts), add new fluid to make it approximately 5.5 dm³ (approximately 5.8 quarts).

9. Fill the fluid into the filler plug.
Brand name: Dia Queen SSTF-I
Filling amount: Approximately 5.5 dm³ (approximately 5.8 quarts)
10. Tighten the filler plug to the specified torque.
Tightening torque: 35 ± 5 N· m (26 ± 4 ft-lb)
11. Install the air cleaner element and air cleaner intake duct. (Refer to GROUP 15 –Air Cleaner P.15-9.)
12. Install the engine room under cover front B assembly. (Refer to GROUP 51 –Under Cover P.51-20.)

TRANSMISSION FLUID CHANGE

1. Remove the engine room under cover front B assembly. (Refer to GROUP 51 –Under Cover P.51-20.)
2. Start the engine, and let it run at idle to warm it up for 15 minutes.
3. Move the shift lever to every position (P, R, N, D, manual mode) (Hold for 20 seconds in each position), and then move it to the P range.
4. Stop the engine.
5. Remove the air cleaner element and air cleaner intake duct. (Refer to GROUP 15 –Air Cleaner P.15-9.)
6. Remove the filler plug.




7. Remove the drain plug, and leave it for 3 minutes to drain the fluid.
NOTE: Because the fluid in the oil cooler, oil filter, and TC-SST assembly cannot be drained, the amount of drained fluid will be approximately 5.5 dm³ (approximately 5.8 quarts).
8. Tighten the drain plug to the specified torque.
Tightening torque: 35 ± 5 N· m (26 ± 4 ft-lb)
9. Fill the fluid into the filler plug.
Brand name: Dia Queen SSTF-I
Filling amount: Approximately 5.5 dm³ (approximately 5.8 quarts)
10. Tighten the filler plug to the specified torque.
Tightening torque: 35 ± 5 N· m (26 ± 4 ft-lb)
11. Install the air cleaner element and air cleaner intake duct. (Refer to GROUP 15 –Air Cleaner P.15-9.)
12. Install the engine room under cover front B assembly. (Refer to GROUP 51 –Under Cover P.51-20.)

12. TWIN CLUTCH SPORT-SHIFT TRANSMISSION OIL FILTER (CHANGE)

M1001018700032

For information concerning the replacement procedures, refer to GROUP 22C TC-SST - Oil filter [P.22C-515](#).





13. TRANSFER OIL (WITH ACTIVE CENTER DIFFERENTIAL) (CHECK OIL LEVEL/CHANGE)

M1001003000305

TRANSFER OIL CHECK

1. Remove the engine room under cover front B assembly. (Refer to GROUP 51, Under cover [P.51-20](#).)
2. Remove the filler plug and gasket.



3. Check that the oil level is not 14 mm (0.6 inch) below the bottom of the oil filler plug hole.
4. Check that the oil is not excessively foul and has moderate viscosity.
5. If the oil level is not in between the upper limit and the lower limit, refill the specified oil to the bottom of the oil filler plug hole.



Brand name: DiaQueen LSD gear oil

6. Install the filler plug and new gasket, then tighten them to the specified torque.

Tightening torque: 32 ± 2 N·m (24 ± 1 ft-lb)

7. Install the engine room under cover front B assembly. (Refer to GROUP 51, Under cover [P.51-20](#).)

TRANSFER OIL CHANGE



1. Remove the engine room under cover front B assembly. (Refer to GROUP 51, Under cover P.51-20.)
2. Remove the drain plug and gasket to drain the oil.
3. Install the drain plug and new gasket, then tighten them to the specified torque.

Tightening torque: $32 \pm 2 \text{ N} \cdot \text{m}$ ($24 \pm 1 \text{ ft-lb}$)

4. Remove the filler plug and gasket, then fill the oil up to the lower edge of the filler plug hole.

Brand name: DiaQueen LSD gear oil

Quantity: 0.8 dm^3 (0.85 quarts)

5. Install the filler plug and new gasket, then tighten them to the specified torque.

Tightening torque: $32 \pm 2 \text{ N} \cdot \text{m}$ ($24 \pm 1 \text{ ft-lb}$)

6. Install the engine room under cover front B assembly. (Refer to GROUP 51, Under cover P.51-20.)

14. RESERVE TANK FLUID (FOR ACTIVE CENTER DIFFERENTIAL) (CHECK FLUID LEVEL)

M1001017500068

FLUID LEVEL CHECK

<WHEN THE SCAN TOOL IS NOT USED>


1. Remove the cargo floor box lid and quarter trim plug on the right of the luggage room.
2. If the vehicle has been run, leave it for 90 min. or more in an ordinary temperature $\{10 - 30^\circ \text{C}$ ($50 - 86^\circ \text{F}$) $\}$ to allow the accumulator internal pressure to drop.

NOTE: If the ambient temperature is 10°C (50°F) or less, allow more time to leave the vehicle to stand idle.

3. Check that the oil reservoir fluid level is in between MAX and MIN.
4. If the fluid level is not in between MAX and MIN, fill the specified fluid.

Brand name: DIAMOND ATF SP III

5. Install the quarter trim plug and cargo floor box lid.



<WHEN THE SCAN TOOL IS USED>

1. Remove the cargo floor box lid and quarter trim plug on the right of the luggage room.

⚠ CAUTION

Turn the ignition switch to the "LOCK (OFF)" position before connecting or disconnecting the scan tool.

2. Set the scan tool to the 16-pin data link connector. (Refer to [P.22C-394.](#))
3. Turn the ignition switch to the ON position.
4. Using the scan tool, forcibly activate the hydraulic unit (item No. 03) to reduce the pressure inside the accumulator.


NOTE:

- With the forced activation (oil level check mode), the hydraulic unit direction valve is operated 20 seconds to right and left, and then the operation is cancelled automatically. Also, using the clear key on the scan tool, the activation can be forcibly cancelled.
- When the functions are suspended by the fail-safe function, the hydraulic unit cannot be forcibly activated.

5. Check that the oil reservoir fluid level is in between MAX and MIN.
6. If the fluid level is not in between MAX and MIN, fill the specified fluid.

Brand name: DIAMOND ATF SP III

7. Install the quarter trim plug and cargo floor box lid.



15. ENGINE COOLANT (CHANGE)

M1001003100670

Required Special Tool:


- MB991871: LLC changer

1. Remove the engine room under cover front A (Refer to GROUP 51, Under Cover [P.51-20.](#))

⚠ WARNING

When removing the radiator cap, use care to avoid contact with hot engine coolant or steam. Place a shop towel over the radiator cap and turn the radiator cap counterclockwise a little to let the pressure escape through the vinyl tube. After relieving the steam pressure, remove the radiator cap by slowly turning it counterclockwise.


2. Drain the engine coolant from the radiator, heater core and engine after unplugging the radiator drain plug and removing the radiator cap.
3. Remove the engine room under cover front B (Refer to GROUP 51, Under Cover [P.51-20.](#))
4. Remove the air cleaner to turbocharger duct (Refer to GROUP 15, Air Cleaner [P.15-9.](#))



5. Disconnect the turbocharger water return hose and drain the engine coolant in the water jacket.
6. Remove the radiator condenser tank and drain the engine coolant.
7. Drain the engine coolant then clean the path of the engine coolant by injecting water into the radiator from the radiator cap area.
8. Connect the turbocharger water return hose.
9. Reinstall the air cleaner to turbocharger duct (Refer to GROUP 15, Air Cleaner P.15-9.)
10. Securely tighten the radiator drain plug.
11. Reinstall the radiator condenser tank.

⚠ CAUTION

Do not use alcohol or methanol anti-freeze or any engine coolants mixed with alcohol or methanol anti-freeze. The use of an improper anti-freeze can cause corrosion of the aluminum components.



12. By referring to the section on engine coolant, select an appropriate concentration for safe operating temperature within the range of 30 to 60%. Use special tool MB991871 to refill the engine coolant up to the top of the radiator port. A convenient mixture is a 50% water and 50% antifreeze solution [freezing point: -31°C (-23.8 °F).]

Recommended antifreeze: Long Life Antifreeze Coolant or an equivalent

Quantity: 7.5 dm³ (7.9 quarts)

[includes 0.65 dm³ (0.63 quarts) in the radiator condenser tank]

NOTE: For how to use special tool MB991871, refer to its manufacturer's instructions.

13. Tighten the radiator cap securely.
 14. Remove the radiator condenser tank cap, and add the engine coolant up to the "FULL" line.
 15. Turn the A/C switch to OFF position to start the engine and warm up until the cooling fan operates.
- NOTE: This step opens the thermostat fully.*
16. Rev the engine several times and then stop it. Check that there are no engine coolant leaks.
 17. Remove the radiator cap with the engine cool, and then refill the engine coolant up to the top of the radiator port.
 18. Tighten the radiator cap securely.

⚠ CAUTION

Do not overfill the radiator condenser tank.

19. Remove the radiator condenser tank cap, and add the engine coolant up to the "FULL" line.
20. Reinstall the engine room under cover front A, B (Refer to GROUP 51, Under Cover P.51-20.)

16. COOLANT HOSES (RADIATOR HOSE, HEATER HOSE) (INSPECT)

M1001009700227

Inspect the surface of radiator hoses and heater hoses for heat and mechanical damage. Hard and brittle rubber, cracking, tears, cuts, abrasions and excessive swelling indicate deterioration of the rubber.

17. DISK BRAKE PADS AND ROTORS (INSPECT FOR WEAR)

M1001003200570

DISK BRAKE PAD CHECK

CAUTION



If there is a significant difference in thickness between the brake pads at right and left, check the sliding area and the runout of the brake disk (Refer to [P.35A-27](#)).

1. Visually check the thickness of brake pad from the inspection hole of the caliper body.

Standard value: 10.0 mm (0.39 inch)

Limit: 2.0 mm (0.08 inch)

2. If the brake pad thickness is less than the limit value, replace the brake pad.





DISK BRAKE PAD REPLACEMENT

<FRONT>

⚠ CAUTION

When replacing, replace both brake pads (right and left) as a set.

1. Remove the parts indicated in the figure, swivel the caliper body upward and retain it with a wire or similar tool.



AC802170AD

2. Remove the following parts from the caliper body.

- (1) Shim
- (2) Brake pad assembly
- (3) Clip

NOTE:

- The brake pad assembly with wear indicator is installed only to the inner side of the brake disk of the left-side brake at factory.
- As for the accessory pad set, the brake pad with wear indicator has been established to the inner side of the brake disk on both right side brake and left side brake.


⚠ CAUTION

Keep grease or other soiling off the pad and brake disk friction surfaces.


3. Clean the piston part, and press the piston into the cylinder using the special tool piston expander (MB990520).
4. Assemble the shim, brake pad assembly and clip to the caliper support, and tighten the guide pin to the specified torque.

Tightening torque: 74 ± 10 N·m (55 ± 7 ft-lb)

NOTE: Install the brake pad assembly (with wear indicator) to the inner side of the brake disk, making sure that the wear indicator is located on the top.



LUBRICATION POINT





<REAR>

⚠ CAUTION

When replacing, replace both brake pads (right and left) as a set.

1. Remove the parts indicated in the figure, swivel the caliper body upward and retain it with a wire or similar tool.





AC709480AB

2. Remove the following parts from the caliper body.

- (1) Shim
- (2) Brake pad assembly
- (3) Clip

NOTE:

- The brake pad assembly with wear indicator is installed only to the inner side of the brake disk of the left-side brake at factory.
- As for the accessory pad set, the brake pad with wear indicator has been established to the inner side of the brake disk on both right side brake and left side brake.


CAUTION

Keep grease or other soiling off the pad and brake disk friction surfaces.


3. Clean the piston part, and press the piston into the cylinder using the special tool piston expander (MB990520).
4. Assemble the shim, brake pad assembly and clip to the caliper support, and tighten the guide pin to the specified torque.

Tightening torque: 44 ± 5 N·m (32 ± 4 ft-lb)

NOTE: Install the brake pad assembly (with wear indicator) to the inner side of the brake disk, making sure that the wear indicator is located on the bottom.




**LUBRICATION POINT
DISK BRAKE ROTOR CHECK**



AC802113 AB

Grease: Niglube RM or equivalent



AC800600 AE

Grease: Repair kit grease (Color: Yellow)

⚠ CAUTION

Disk brakes must be kept within the allowable service values in order to maintain normal brake operation.

Before turning the brake disk, the following conditions should be checked.

Inspection item	Remark
Scratches, rust, saturated lining materials and wear	<ul style="list-style-type: none"> If the vehicle is not driven for a long period of time, sections of the disks that are not in contact with the pads will become rusty, causing noise and shuddering. If grooves and scratches resulting from excessive disk wear are not removed prior to installing a new pad assembly, there will be inadequate contact between the disk and the lining (pad) until the pads conform to the disk.
Run-out	Excessive run-out of the disks will increase the pedal depression resistance due to piston kick-back.
Change in thickness (parallelism)	If the thickness of the disk changes, this will cause pedal pulsation, shuddering and surging.
Inset or warping (flatness)	Overheating and improper handling while servicing will cause warping or distortion.

BRAKE DISK THICKNESS CHECK

- Using a micrometer, measure disk thickness at eight positions, approximately 45 degrees apart and 10 mm (0.4 inch) in from the outer edge of the disk.

Standard value:

24.0 mm (0.94 inch) <Front>

10.0 mm (0.39 inch) <Rear>

Limit:



22.4 mm (0.88 inch) <Front>

8.4 mm (0.33 inch) <Rear>




NOTE: Thickness variation (at least 8 positions) should not be more than 0.015 mm (0.0006 inch).

⚠ CAUTION

- After a new brake disk is installed, always grind the brake disk with on-the-car type brake lathe. If this step is not carried out, the brake disk run-out exceeds the specified value, resulting in judder.
 - When the on-the-car type lathe is used, first install M12 flat washer on the stud bolt in the brake disk side according to the figure, and then install the adapter. If the adapter is installed with M12 flat washer not seated, the brake disk rotor may be deformed, resulting in inaccurate grinding.
 - Grind the brake disk with all wheel nuts diagonally and equally tightened to the specified torque 100 N·m (74 ft-lb). When all numbers of wheel nuts are not used, or the tightening torque is excessive or not equal, the brake disk rotor or drum may be deformed, resulting in judder.
- If the disk thickness is less than the limits, replace it with a new one. If thickness variation exceeds the specification, turn rotor with an on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent). If the calculated final thickness after turning the rotor is less than the standard value, replace the disk.

**FRONT BRAKE DISK RUN-OUT CHECK AND CORRECTION**

- Remove the brake assembly, and then hold it with wire.
- Temporarily install the disk with the hub nut.



- Place a dial gauge approximately 5 mm (0.2 inch) from the outer circumference of the brake disk, and measure the run-out of the disk.

Limit:

0.06 mm (0.0024 inch) <Front>

0.08 mm (0.0032 inch) <Rear>

- When the run-out exceeds the limit value, correct the brake disk run-out in the following procedure.

- Before removing the brake disk, mark the stud bolt on the side of greater run-out and its both sides with a chalk.
- Check for wheel bearing looseness in the axial direction (Refer to GROUP 26 –On-vehicle Service, Wheel bearing play check [P.26-10](#) <Front> or GROUP 27B –On-vehicle Service, Wheel bearing end play check [P.27B-17](#) <Rear>).
- When the looseness is within the limit value, install the brake disk after changing the phase between the hub and the brake disk, then check the run-out of the brake disk again.

CAUTION

- After a new brake disk is installed, always grind the brake disk with on-the-car type brake lathe. If this step is not carried out, the brake disk run-out exceeds the specified value, resulting in judder.
 - When the on-the-car type lathe is used, first install M12 flat washer on the stud bolt in the brake disk side according to the figure, and then install the adapter. If the adapter is installed with M12 flat washer not seated, the brake disk rotor may be deformed, resulting in inaccurate grinding.
 - Grind the brake disk with all wheel nuts diagonally and equally tightened to the specified torque 100 N·m (74 ft-lb). When all numbers of wheel nuts are not used, or the tightening torque is excessive or not equal, the brake disk rotor or drum may be deformed, resulting in judder.
- If the run-out cannot be corrected by changing the phase of the brake disk, replace the brake disk or grind it with the on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent).

18. BRAKE HOSES (CHECK FOR DETERIORATION OR LEAKS)

M1001003400563


Inspection of brake hoses should be included in all brake service operations.

The hoses should be checked for:

1. Incorrect length, severe surface cracking, pulling, scuffing or worn spots. (If the fabric casing of the hoses is exposed by cracks or abrasion in the rubber hose cover, the hoses should be replaced. Eventual deterioration of the hose and possible bursting failure may occur).
2. Incorrect installation, twisting or interference with wheel, tire or chassis.

19. BALL JOINT AND STEERING LINKAGE SEALS (INSPECT FOR GREASE LEAKS AND DAMAGE)


M1001003500559



1. These components, which are permanently lubricated at the factory, do not require periodic lubrication. Damaged seals and boots should be replaced to prevent leakage or grease contamination.
2. Inspect the dust cover and boots for proper sealing, leakage and damage, and replace them if defective.

20. DRIVE SHAFT BOOTS (INSPECT FOR GREASE LEAKS AND DAMAGE)

M1001003600556



1. These components, which are permanently lubricated at the factory, do not require periodic lubrication. Damaged seals and boots should be replaced to prevent leakage or grease contamination.
2. Inspect the dust cover and boots for proper sealing, leakage and damage. Replace them if defective.

21. SUSPENSION SYSTEM (INSPECT FOR LOOSENESS AND DAMAGE)

M1001009600275

Visually inspect the front/rear suspension components for deterioration and damage. Re-tighten the front/rear suspension components retaining bolts to specified torque.

22. REAR AXLE OIL (WITH LSD) (CHANGE)

M1001007200174

1. Remove the filler plug.
2. Remove the drain plug and drain oil.
3. Tighten the drain plug to the specified torque (Refer to [P.27B-29](#)).
4. Add the oil until the level comes to the lower portion of the filler plug hole.

Specified gear oil: MITSUBISHI Genuine DIA QUEEN LSD gear oil

Amount to use: Approx. 0.55 dm³(0.58 quart)

5. Tighten the filler plug to the specified torque (Refer to [P.27B-29](#)).

23. TIRES (ROTATE)


M1001008900585

Rotate tires regularly to equalize tire wear and help extend tire life. Recommended tire rotation is every 12,000 km (7,500 miles).

Timing for the rotation may vary according to vehicle condition, road surface conditions, and individual driver's habits.

When rotating tires, check for uneven wear, damage, and wheel alignment. Abnormal wear is usually caused by incorrect tire pressure, improper wheel alignment, out-of balance wheels, or severe braking.


The first rotation is the most important, to achieve more uniform wear for all tires on the vehicle.



24. AIR PURIFIER FILTER (REPLACE)

M1001009000206

1. Remove the glove box (Refer to GROUP 52A –glove box, [P.52A-6](#)).
2. Loosen the two lugs as shown to replace the clean air filter.
3. Install the glove box.



MAINTENANCE SERVICE <2.4L ENGINE>**1. FUEL SYSTEM (TANK, PIPE LINE AND CONNECTION, AND FUEL TANK FILLER TUBE CAP) (CHECK FOR LEAKS)**

M1001001600141

Check for damage or leakage in the fuel lines and connections.

2. FUEL HOSES (CHECK CONDITION)

M1001001700148

1. Inspect the surface of fuel hoses for heat and mechanical damage. Hard and brittle rubber, cracking, tears, cuts, abrasions and excessive swelling indicate deterioration of the rubber.
2. If the fabric casing of the rubber hose is exposed by cracks and abrasions in the fuel system, the hoses should be replaced.


3. AIR CLEANER ELEMENT (REPLACE)

M1001001800394

The air cleaner element will become dirty during use, reducing its effectiveness. Replace it with a new one.

Replacement of air cleaner element

1. Unclamp the air cleaner housing.
2. Remove the air cleaner element and install a new one.
3. When clamping the air cleaner housing in place, be sure that the cover is completely closed.

**4. EVAPORATIVE EMISSION CONTROL SYSTEM (EXCEPT EVAPORATIVE EMISSION CANISTER) (CHECK FOR LEAKS AND CLOGGING)**

M1001001900380

If the fuel-vapor vent line is clogged or damaged, fuel vapor will escape into the atmosphere causing excessive emissions. Disconnect the line at both ends, and blow it clean with compressed air. Remove the fuel tank filler tube cap from the filler tube and check to see if there is evidence that the seal makes improper contact to the filler tube.

5. SPARK PLUGS (REPLACE)

M1001002000551

⚠ CAUTION

Iridium plugs are used. Use care not to damage the electrode of the plugs. Do not adjust the spark plug gap.

1. Spark plugs must spark properly to assure proper engine performance and reduce exhaust emission level.

Therefore, they should be replaced periodically with new ones.

Spark plug type

Maker	Identification No.
NGK	FR5EI
DENSO	K16PSR-B8

2. The new plugs should be checked for the proper gap.

Spark plug gap: 0.7 –0.8 mm (0.028 –0.031 inch)

3. Install the spark plugs and tighten to 25 ± 4 N·m (18 ± 3 ft-lb).

6. INTAKE AND EXHAUST VALVE CLEARANCE (INSPECT AND ADJUST)

M1001012900287



NOTE: Perform the valve clearance check and adjustment at the engine cold state.

1. Remove all of the ignition coils.
2. Remove the cylinder head cover.

⚠ CAUTION

Turn the crankshaft always clockwise.

3. Turn the crankshaft clockwise, and align the timing mark on the exhaust camshaft sprocket against the upper face of the cylinder head as shown in Figure. Therefore, No. 1 cylinder goes to the compression top dead center.







4. Using a thickness gauge, measure the valve clearance with the arrow shown in Figure. If deviated from the standard value, make note for the valve clearance.

Standard value:

Intake valve 0.20 ± 0.03 mm (0.008 ± 0.001 inch)

Exhaust valve 0.30 ± 0.03 mm (0.012 ± 0.001 inch)



5. Turn the crankshaft clockwise 360 degrees, and put the timing mark on the exhaust camshaft sprocket in position shown in Figure. Therefore, No. 4 cylinder goes to the compression top dead center.

6. Check the valve clearance with the arrow shown in Figure. In the same procedure as 4.

7. If the valve clearance is deviated from the standard value, remove the camshaft and the valve tappet. For the camshaft removal (Refer to GROUP 11C, Camshaft –Removal and Installation P.11C-24).

8. Using a micrometer, measure the thickness of the removed valve tappet.

9. Calculate the thickness of the newly installed valve tappet through the following equation.

A: thickness of newly installed valve tappet

B: thickness of removed valve tappet

C: measured valve clearance

Equation

$$\text{Intake valve: } A = B + [C - 0.20 \text{ mm (0.008 inch)}]$$

$$\text{Exhaust valve: } A = B + [C - 0.30 \text{ mm (0.012 inch)}]$$

NOTE: The valve tappet ranges 3,000 –3,690 mm (0.1181 – 0.1453 inch) and has 47 types per 0.015 mm (0.0006 inch). The thickness below a decimal point is stamped on the reverse side of the valve tappet.

10. Install the valve tappet selected through the procedure 9, and put the camshaft in position. For the camshaft installation (Refer to GROUP 11C, Camshaft –Removal and Installation P.11C-24).

11. After installing the timing chain, measure the valve clearance using the procedure 3 to 6. Confirm the clearance is within the standard value.

CAUTION

Completely remove all the old FIPG, which might be remaining among the components.

12. After completely removing the liquid gasket adhering on the timing chain case, cylinder head and cylinder head cover, degrease them.



CAUTION

The cylinder head cover should be installed within 3 minutes of applying liquid gasket.

13. Apply a 4 mm (0.16 in) bead of liquid gasket as illustrated.

Specified sealant:

THREE BOND 1217G or equivalent



14. Install the cylinder head cover and tighten the tightening bolts using the following procedures.

(1) Temporarily tighten to the following torque in order shown in the illustration.

Tightening torque: 3.0 ± 1.0 N·m (27 ± 8 in-lb)

(2) Tighten to the specified torque in order shown in the illustration.

Specified torque: 5.5 ± 0.5 N·m (49 ± 4 in-lb)

15. Install the ignition coils.

7. DRIVE BELT (FOR THE GENERATOR AND POWER STEERING OIL PUMP) (CHECK CONDITION)

M1001002500664

1. Remove the radiator condenser tank mounting bolts.
2. Move the radiator condenser tank to a place where it will not be a hindrance when checking the drive belt tension.

CAUTION


Check the drive belt tension after turning the crankshaft clockwise one turn or more.

3. Make sure that the indicator mark on the auto-tensioner is within the area marked with A in the illustration.
4. If the mark is out of the area, replace the drive belt. (Refer to GROUP 11C –Crankshaft Pulley.

NOTE: The drive belt tension check is not necessary as the auto-tensioner is adopted.

5. Tighten the radiator condenser tank mounting bolts to the specified torque.

Tightening torque: 12 ± 2 N·m (102 ± 22 in-lb)



8. EXHAUST SYSTEM (CONNECTIONS PORTION OF MUFFLER, MUFFLER PIPES AND CONVERTER HEAT SHIELDS) (CHECK AND SERVICE)

M1001005800482

1. Check for holes and exhaust gas leaks due to damage, corrosion, etc.
2. Check the joints and connections for looseness and exhaust gas leaks.
3. Check the rubber hangers and brackets for damage.

9. ENGINE OIL (CHANGE)

M1001002600735



1. Start the engine and allow it to warm up until the temperature of the engine coolant reaches 80 –90° C (176 – 194° F.)

⚠ WARNING

Use care as engine oil could be hot.

2. Remove the engine oil filler cap.
3. Remove the engine oil pan drain plug to drain engine oil.
4. Install a new engine oil pan drain plug gasket so that it faces in the direction shown in the illustration, and then tighten the engine oil pan drain plug to the specified torque.

Tightening torque: 39 ± 5 N· m (29 ± 3 ft-lb)



5. Refill the specified quantity of engine oil.

Specified Engine Oil: Engine oils displaying ILSAC certification symbol ("Starburst" symbol) or conforming to the API classification SM or higher

Total quantity: 4.6 dm³ (4.8 quarts)

NOTE: SAE 5W-20 engine oil is strongly recommended for optimum fuel economy and cold starting. SAE 10W-30 may be used when the normal operating temperature is above 38° C (100° F.)

6. Install the engine oil filler cap.
7. Let the engine run for a few minutes.
8. Stop the engine, and then check the engine oil level using the engine oil dipstick after a few minutes.

M1001002700646

10. ENGINE OIL FILTER (REPLACE)

Required Special Tool:

- MB991396: Oil Filter Wrench

1. Start the engine and allow it to warm up until the temperature of the engine coolant reaches 80 –90° C (176 – 194° F.)



⚠ WARNING

Use care as engine oil could be hot.

2. Remove the engine oil filler cap.
3. Remove the engine oil pan drain plug to drain engine oil.
4. Use the respective tool in the following table to remove the engine oil filter.

Number	Special tool
MD360935	MB991396 or equivalent

5. Clean the filter bracket side mounting surface and ensure the old O-ring has been removed.



6. Apply a small amount of engine oil to the O-ring of the new engine oil filter.
7. Screw on the engine oil filter by hand until it touches the surface of the flange and then tighten it with an oil filter wrench.

Number	Special tool	Tightening torque
MD360935	MB991396 or equivalent	Approximately 1 turn [14 ± 2 N· m (124 ± 17 in-lb)]





8. Install the engine oil pan drain plug and refill the engine oil (Refer to P.12-5.)
9. Rev the engine a few times, and check to be sure that no engine oil leaks from the installation section of the engine oil filter.

11. TRANSMISSION OIL <M/T> (CHECK OIL LEVEL AND CONDITION)

M1001002800342

TRANSMISSION OIL LEVEL CHECK

1. Remove the oil filler plug and gasket.
2. Check that the oil level is up to the lower edge of the filler plug hole.
3. Check that the oil is not noticeably dirty.
4. Tighten the filler plug and new gasket to the specified torque.

Tightening torque: 49 ± 19 N· m (37 ± 14 ft-lb)**TRANSMISSION OIL REPLACEMENT**

1. Remove the filler plug and gasket.
2. Remove the drain plug and drain the oil.
3. Tighten the drain plug to the specified torque.

Tightening torque: 49 ± 19 N· m (37 ± 14 ft-lb)

4. Fill with DiaQueen NEW MULTI GEAR OIL API classification GL-3, SAE 75W-80 until the level comes to the lower portion of filler plug hole.

Quantity: 2.5 dm³ (2.6 quarts)

5. Tighten the filler plug and new gasket to the specified torque.

Tightening torque: 49 ± 19 N· m (37 ± 14 ft-lb)

12. TRANSMISSION FLUID <CVT> (CHANGE FLUID)

M1001002900598

TRANSMISSION FLUID CHECK


⚠ CAUTION

Replace the transmission fluid whenever the transaxle is replaced with a new one or the vehicle is driven in harsh conditions.

1. Drive the vehicle until the transmission fluid is warmed up to the normal operating temperature 70 –80°C (158 –176°F).

NOTE: Use scan tool to measure the transmission fluid temperature.

NOTE: When a certain amount of time is required to warm up the transmission fluid to the normal operating temperature 70 –80°C (158 –176°F), check the oil level referring to the characteristics chart.



2. Park the vehicle on a level surface.
3. Move the selector lever to every position to fill the torque converter and the hydraulic circuit with the transmission fluid, and then move the selector lever to "P" or "N" range.
4. Wipe clean the area around the dipstick, and then remove the dipstick to check the condition of the transmission fluid.


NOTE: If the transmission fluid smells burnt or is excessively deteriorated or dirty, the transmission fluid is contaminated with particles of the metal bushings and friction material. In these cases, the transaxle must be overhauled.

5. Check that the transmission fluid level is within the "H" area on the dipstick. If the fluid level is low, add the transmission fluid to the "H" level.


Transmission fluid: DIA QUEEN CVTF-J1

NOTE: When the transmission fluid level is low, the oil pump sucks air together with the transmission fluid, and produces air bubbles in the hydraulic circuit. The air bubbles in the hydraulic circuit decreases the hydraulic pressure, causing the delayed shift or slippage of the belt, clutch, and brake. When the transmission fluid level is too high, the fluid is stirred by the gear and foams up, and the problems similar to those when the transmission fluid level is low will occur. In either case, air bubbles cause the overheat and oxidation of the transmission fluid, which prevents normal operation of the valve, clutch, and brake. Beside, when the transmission fluid is foamy, it flows out of the transaxle vent hole. This may be taken as the fluid leakage by mistake.

6. Insert the dipstick securely.



TRANSMISSION FLUID REPLACEMENT



1. Remove the drain plug on the bottom of the transaxle case to drain the transmission fluid.

Draining amount: Approximately 6.0 dm³ (6.3 qt)

2. Install the drain plug with a new gasket to the transaxle case, and tighten it to the specified torque.

Tightening torque: 34 ± 2 N·m (25 ± 2 ft-lb)

⚠ CAUTION

If the transaxle case becomes full before filling 6.0 dm³ (6.3 qt) of transmission fluid, stop filling the transmission fluid.

3. Fill in the new transmission fluid through the filler tube.



Filling amount: Approximately 6.0 dm³ (6.3 qt)

Transmission fluid: DIA QUEEN CVTF-J1

4. Start up the engine and let it idle for 1 to 2 minutes.
5. Move the selector lever to every position, and then move it to the "P" or "N" range.
6. Stop the engine and perform the above steps 1 to 5 again.
7. Stop the engine, and discharge a small amount of transmission fluid to check for fouling. If fouling is found, repeat steps 1 to 5 until clean transmission fluid comes out.
8. Drive the vehicle until the transmission fluid is warmed up to the normal operating temperature 70 – 80 °C (158 – 176 °F), and check the transmission fluid level. It must be within the "H" area on the dipstick.

NOTE: The "C" level is for reference only. Use the "H" level as the criteria.

NOTE: Use scan tool to measure the transmission fluid temperature.



NOTE: When a certain amount of time is required to warm up the transmission fluid to the normal operating temperature 70 – 80 °C (158 – 176 °F), check the fluid level referring to the characteristics chart.

9. Adjust the transmission fluid level to the specified level.
Refill the transmission fluid when the fluid level is low, and drain the transmission fluid through the drain plug when the fluid level is high.
10. Securely insert the dipstick into the filler tube.
11. TCM records the deterioration level of the transmission fluid.
After replacing the transmission fluid with new one, use scan tool to reset the deterioration level recorded in TCM.

13. ENGINE COOLANT (CHANGE)

M1001003100636

Required Special Tool:


- MB991871: LLC changer


1. Remove the engine room under cover front A (Refer to GROUP 51, Under Cover [P.51-20](#).)

⚠ WARNING

When removing the radiator cap, use care to avoid contact with hot engine coolant or steam. Place a shop towel over the radiator cap and turn the radiator cap counterclockwise a little to let the pressure escape through the vinyl tube. After relieving the steam pressure, remove the radiator cap by slowly turning it counterclockwise.

2. Drain the engine coolant from the radiator, heater core and engine after unplugging the radiator drain plug and removing the radiator cap.
3. Remove the engine room under cover front B (Refer to GROUP 51, Under Cover [P.51-20](#).)
4. Disconnect the cooling water line hose and drain the engine coolant in the water jacket.
5. Remove the radiator condenser tank and drain the engine coolant.
6. Drain the engine coolant then clean the path of the engine coolant by injecting water into the radiator from the radiator cap area.
7. Connect the cooling water line hose.
8. Securely tighten the radiator drain plug.
9. Reinstall the radiator condenser tank.



**⚠ CAUTION**

Do not use alcohol or methanol anti-freeze or any engine coolants mixed with alcohol or methanol anti-freeze. The use of an improper anti-freeze can cause corrosion of the aluminum components.

10. By referring to the section on engine coolant, select an appropriate concentration for safe operating temperature within the range of 30 to 60%. Use special tool MB991871 to refill the engine coolant up to the top of the radiator port. A convenient mixture is a 50% water and 50% antifreeze solution [freezing point: -31°C (-23.8°F).]

Recommended antifreeze: Long Life Antifreeze Coolant or an equivalent

Quantity: 7.0 dm^3 (7.4 quarts)

[includes 0.65 dm^3 (0.63 quarts) in the radiator condenser tank]

NOTE: For how to use special tool MB991871, refer to its manufacturer's instructions.

11. Tighten the radiator cap securely.
12. Remove the radiator condenser tank cap, and add the engine coolant up to the "FULL" line.
13. Turn the A/C switch to OFF position to start the engine and warm up until the cooling fan operates.

NOTE: This step opens the thermostat fully.

14. Rev the engine several times and then stop it. Check that there are no engine coolant leaks.
15. Remove the radiator cap with the engine cool, and then refill the engine coolant up to the top of the radiator port.
16. Tighten the radiator cap securely.

⚠ CAUTION

Do not overfill the radiator condenser tank.

17. Remove the radiator condenser tank cap, and add the engine coolant up to the "FULL" line.
18. Reinstall the engine room under cover front A, B (Refer to GROUP 51, Under Cover [P.51-20.](#))

14. COOLANT HOSES (RADIATOR HOSE, HEATER HOSE) (INSPECT)

M1001009700142

Inspect the surface of radiator hoses and heater hoses for heat and mechanical damage. Hard and brittle rubber, cracking, tears, cuts, abrasions and excessive swelling indicate deterioration of the rubber.

15. DISK BRAKE PADS AND ROTORS (INSPECT FOR WEAR)

M1001003200525

DISK BRAKE PAD CHECK

⚠ CAUTION



If there is a significant difference in thickness between the brake pads at right and left, check the sliding area and the runout of the brake disk (Refer to [P.35A-27](#)).

1. Visually check the thickness of brake pad from the inspection hole of the caliper body.

Standard value: 10.0 mm (0.39 inch)

Limit: 2.0 mm (0.08 inch)

2. If the brake pad thickness is less than the limit value, replace the brake pad.




DISK BRAKE PAD REPLACEMENT


<FRONT>

⚠ CAUTION

When replacing, replace both brake pads (right and left) as a set.

1. Remove the parts indicated in the figure, swivel the caliper body upward and retain it with a wire or similar tool.





2. Remove the following parts from the caliper body.

- (1) Shim
- (2) Brake pad assembly
- (3) Clip

NOTE:

- The brake pad assembly with wear indicator is installed only to the inner side of the brake disk of the left-side brake at factory.
- As for the accessory pad set, the brake pad with wear indicator has been established to the inner side of the brake disk on both right side brake and left side brake.



CAUTION

Keep grease or other soiling off the pad and brake disk friction surfaces.

3. Clean the piston part, and press the piston into the cylinder using the special tool piston expander (MB990520).
4. Assemble the shim, brake pad assembly and clip to the caliper support, and tighten the guide pin to the specified torque.

Tightening torque: 44 ± 5 N·m (32 ± 4 ft-lb)

NOTE: Install the brake pad assembly (with wear indicator) to the inner side of the brake disk, making sure that the wear indicator is located on the top.






Grease: Repair kit grease (Color: Translucent red), Niglube RX-2 or equivalent

<REAR>

CAUTION

When replacing, replace both brake pads (right and left) as a set.

1. Remove the parts indicated in the figure, swivel the caliper body upward and retain it with a wire or similar tool.




AC807396 AB

2. Remove the following parts from the caliper body.

- (1) Shim
- (2) Brake pad assembly
- (3) Clip

NOTE:

- The brake pad assembly with wear indicator is installed only to the inner side of the brake disk of the left-side brake at factory.
- As for the accessory pad set, the brake pad with wear indicator has been established to the inner side of the brake disk on both right side brake and left side brake.



⚠ CAUTION

Keep grease or other soiling off the pad and brake disk friction surfaces.


3. Clean the piston part, and press the piston into the cylinder using the special tool piston expander (MB990520).
4. Assemble the shim, brake pad assembly and clip to the caliper support, and tighten the guide pin to the specified torque.

Tightening torque: 44 ± 5 N·m (32 ± 4 ft-lb)

NOTE: Install the brake pad assembly (with wear indicator) to the inner side of the brake disk, making sure that the wear indicator is located on the bottom.

LUBRICATION POINT

DISK BRAKE ROTOR CHECK



Grease: Niglube RM or equivalent


⚠ CAUTION

Disk brakes must be kept within the allowable service values in order to maintain normal brake operation.

Before turning the brake disk, the following conditions should be checked.

Inspection item	Remark
Scratches, rust, saturated lining materials and wear	<ul style="list-style-type: none"> • If the vehicle is not driven for a long period of time, sections of the disks that are not in contact with the pads will become rusty, causing noise and shuddering. • If grooves and scratches resulting from excessive disk wear are not removed prior to installing a new pad assembly, there will be inadequate contact between the disk and the lining (pad) until the pads conform to the disk.
Run-out	Excessive run-out of the disks will increase the pedal depression resistance due to piston kick-back.
Change in thickness (parallelism)	If the thickness of the disk changes, this will cause pedal pulsation, shuddering and surging.
Inset or warping (flatness)	Overheating and improper handling while servicing will cause warping or distortion.

BRAKE DISK THICKNESS CHECK



1. Using a micrometer, measure disk thickness at eight positions, approximately 45 degrees apart and 10 mm (0.4 inch) in from the outer edge of the disk.

Standard value:

26.0 mm (1.02 inches) <Front>

10.0 mm (0.39 inch) <Rear>

Limit:


24.4 mm (0.96 inch) <Front>

8.4 mm (0.33 inch) <Rear>

NOTE: Thickness variation (at least 8 positions) should not be more than 0.015 mm (0.0006 inch).



CAUTION

- After a new brake disk is installed, always grind the brake disk with on-the-car type brake lathe. If this step is not carried out, the brake disk run-out exceeds the specified value, resulting in judder.
 - When the on-the-car type lathe is used, first install M12 flat washer on the stud bolt in the brake disk side according to the figure, and then install the adapter. If the adapter is installed with M12 flat washer not seated, the brake disk rotor may be deformed, resulting in inaccurate grinding.
 - Grind the brake disk with all wheel nuts diagonally and equally tightened to the specified torque 100 N·m (74 ft-lb). When all numbers of wheel nuts are not used, or the tightening torque is excessive or not equal, the brake disk rotor or drum may be deformed, resulting in judder.
2. If the disk thickness is less than the limits, replace it with a new one. If thickness variation exceeds the specification, turn rotor with an on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent). If the calculated final thickness after turning the rotor is less than the standard value, replace the disk.



FRONT BRAKE DISK RUN-OUT CHECK AND CORRECTION

1. Remove the brake assembly, and then hold it with wire.
2. Temporarily install the disk with the hub nut.



- Place a dial gauge approximately 5 mm (0.2 inch) from the outer circumference of the brake disk, and measure the run-out of the disk.


Limit:**0.06 mm (0.0024 inch) <Front>****0.08 mm (0.0032 inch) <Rear>**

- When the run-out exceeds the limit value, correct the brake disk run-out in the following procedure.

- Before removing the brake disk, mark the stud bolt on the side of greater run-out and its both sides with a chalk.
- Check for wheel bearing looseness in the axial direction (Refer to GROUP 26 –On-vehicle Service, Wheel bearing play check P.26-10 <Front> or GROUP 27A –On-vehicle Service, Wheel bearing end play check P.27A-5 <Rear>).
- When the looseness is within the limit value, install the brake disk after changing the phase between the hub and the brake disk, then check the run-out of the brake disk again.

CAUTION

- After a new brake disk is installed, always grind the brake disk with on-the-car type brake lathe. If this step is not carried out, the brake disk run-out exceeds the specified value, resulting in judder.
 - When the on-the-car type lathe is used, first install M12 flat washer on the stud bolt in the brake disk side according to the figure, and then install the adapter. If the adapter is installed with M12 flat washer not seated, the brake disk rotor may be deformed, resulting in inaccurate grinding.
 - Grind the brake disk with all wheel nuts diagonally and equally tightened to the specified torque 100 N·m (74 ft-lb). When all numbers of wheel nuts are not used, or the tightening torque is excessive or not equal, the brake disk rotor or drum may be deformed, resulting in judder.
- If the run-out cannot be corrected by changing the phase of the brake disk, replace the brake disk or grind it with the on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent).



16. BRAKE HOSES (CHECK FOR DETERIORATION OR LEAKS)

M1001003400529

Inspection of brake hoses should be included in all brake service operations.


The hoses should be checked for:

1. Incorrect length, severe surface cracking, pulling, scuffing or worn spots. (If the fabric casing of the hoses is exposed by cracks or abrasion in the rubber hose cover, the hoses should be replaced. Eventual deterioration of the hose and possible bursting failure may occur).
2. Incorrect installation, twisting or interference with wheel, tire or chassis.

17. BALL JOINT AND STEERING LINKAGE SEALS (INSPECT FOR GREASE LEAKS AND DAMAGE)

M1001003500526


1. These components, which are permanently lubricated at the factory, do not require periodic lubrication. Damaged seals and boots should be replaced to prevent leakage or grease contamination.
2. Inspect the dust cover and boots for proper sealing, leakage and damage, and replace them if defective.



18. DRIVE SHAFT BOOTS (INSPECT FOR GREASE LEAKS AND DAMAGE)

M1001003600523

1. These components, which are permanently lubricated at the factory, do not require periodic lubrication. Damaged seals and boots should be replaced to prevent leakage or grease contamination.
2. Inspect the dust cover and boots for proper sealing, leakage and damage. Replace them if defective.



19. SUSPENSION SYSTEM (INSPECT FOR LOOSENESS AND DAMAGE)

M1001009600242

Visually inspect the front/rear suspension components for deterioration and damage. Re-tighten the front/rear suspension components retaining bolts to specified torque.

20. TIRES (ROTATE)


M1001008900552

Rotate tires regularly to equalize tire wear and help extend tire life. Recommended tire rotation is every 12,000 km (7,500 miles).

Timing for the rotation may vary according to vehicle condition, road surface conditions, and individual driver's habits.


When rotating tires, check for uneven wear, damage, and wheel alignment. Abnormal wear is usually caused by incorrect tire pressure, improper wheel alignment, out-of balance wheels, or severe braking.

The first rotation is the most important, to achieve more uniform wear for all tires on the vehicle.

**21. AIR PURIFIER FILTER (REPLACE)**

M1001009000176

1. Remove the glove box (Refer to GROUP 52A –glove box, P.52A-6).
2. Loosen the two lugs as shown to replace the clean air filter.
3. Install the glove box.



MAIN SEALANT AND ADHESIVE TABLE

M1001003800594

Application		3M™/three bond No.	Loctite®/permatex®No.
ENGINE AND DRIVETRAIN	Between rocker cover, cylinder head and timing chain case.	Three bond 1217G (Mitsubishi Genuine Part No.1000A923), Three bond 1227D (Mitsubishi Genuine Part No.MZ100792)	-
	Between cylinder head gasket. Between timing chain case.	Three bond 1217G (Mitsubishi Genuine Part No.1000A923)	-
	Between oil pan	Three bond 1217G (Mitsubishi Genuine Part No.1000A923), Three bond 1227D (Mitsubishi Genuine Part No.MZ100792), Three bond 1207F (Mitsubishi Genuine Part No.MD970389)	Loctite®5971, Loctite®5900, Loctite®5970
	Between engine oil pressure switch	Three bond 1215, Three bond 1212D	-
	Between engine coolant temperature switch	Three bond 1324	Loctite®262
WEATHERSTRIPPING FOR GLASS	Between tempered glass, body flanges, and weatherstrip	3M™ AAD Part No. 8509 Auto Bedding and Glazing Compound or 3M™ AAD Part No. 8633 Windo-weld Resealant	-
WEATHERSTRIPPING FOR GLASS	Between laminated glass and weatherstrip	3M™ AAD Part No. 8633	-
INTERIORS	Adhesive of vinyl chloride cloth	3M™ AAD Part No. 8088 General Trim Adhesive or 3M™ AAD Part No. 8064 Vinyl Trim Adhesive	Permatex® Vinyl Repair Kit No.81786
	Adhesion of door weatherstrip	3M™ AAD Part No. 8001 (yellow) or 3M™ AAD Part No. 8008 (black) Super Weatherstrip Adhesive or 3M™ AAD Part No. 8011 Black Weatherstrip Adhesive	Permatex® Super Black Weatherstrip Adhesive No.82, 81850
	Sealing of various grommets and packing	3M™ AAD Part No. 8509 or 3M™ AAD Part No. 8678	-
	Adhesion of headliners and various interior decorative materials	3M™ AAD Part No. 8088 General Trim Adhesive or 3M™ AAD Part No. 8090 Super Trim Adhesive	Permatex® Spray Adhesive No.82019

**GENERAL
MAIN SEALANT AND ADHESIVE TABLE**

Application		3M™/three bond No.	Loctite®/permatex®No.
BODY SEALANTS	Sealing of sheet metal joints, drip rail, floor, side panels, front panel, liftgate hinge	3M™ AAD Part No. 8531 Heavy Drip-Check Sealer (gray) 3M™ ADD Part No. 8646 or 3M™ AAD Part No. 8302 Ultrapro Autobody Sealant (clear) or 3M™ AAD Part No. 8361 Urethane A/B Sealant (gray or white)	-
	Miscellaneous body sealants (original mounted w/adhesive tape) <ul style="list-style-type: none"> • Waterproof door film • Mud guard • Rear combination lamp 	3M™ AAD Part No. 8633 Windo-weld Resealant	-
	Fuel Tank and Pad	3M™ AAD Part No. 8088 General Trim Adhesive or 3M™ AAD Part No. 8090 Super Trim Adhesive	Permatex® Spray Adhesive No.82019
CHASSIS SEALANT	Sealant of various flange faces and threaded parts. Packing of fuel gauge unit	3M™ AAD Part No. 8730 High Strength Red Threadlock or 3M™ AAD Part No. 8731 Medium Strength Blue Threadlocker	Loctite®272 High Strength and High Temperature 27200
	Sealing of various threaded parts, dust covers. Differential carrier packing, dust covers and ball joint and linkage. Packing and shims of steering box, sealing of rack support cover and top cover of steering box housing, seal of junction face of knuckle arm flange	3M™ AAD Part No. 8672 Ultrapro High Temp. Silicone Gasket or 3M™ AAD Part No. 8679 (black) or 3M™ AAD Part No. 8678 (black) Press-In-Place Silicone gasket strips 3M™ AAD Part No. 8661 or 3M™ AAD Part No. 8663 Super Silicone sealant	Permatex® The Right Stuff No.25223
	Seal of brake shoe hold down pin and wheel cylinder of drum brakes	3M™ AAD Part No. 8633 Windo-weld Resealant	-
QUICK FIX ADHESIVE	-	3M™ AAD Part No. 8155 Quick Fix Adhesive	Loctite®Quicktite Super Glue 21309
ANAEROBIC STRONG SEALING AGENT	Fixing of various threads, bolts, screws. Fixing of differential drive gear bolt, Connecting of tilt steering bolt. Fan, pulley, gear Sealing of small gaps and flange faces	3M™ AAD Part No. 8730 High Strength Threadlocker or 3M™ AAD Part No. 8731 Medium Strength Threadlocker	Loctite®271, High-Strength Threadlocker 27100 or 27200
UNDER COATING AGENT	-	3M™ AAD Part No. 8883 Rubberized Undercoating Aerosol or 3M™ AAD Part No. 8864 Body Schutz Undercoating (qt)	Permatex® Heavy-Duty Undercoating 81833